





**BARCO Projection Systems**

**SECTION K**

**service sheet**



**Input module R762228**



Name	Interconnection	Article nr.
Date	22-03-1995	76 2228
Drawn	JVDY	Checked
		PDC

BARCO PROJECTION SYSTEMS

COMP.	LOC.	COMP.	LOC.	COMP.	LOC.	COMP.	LOC.	COMP.	LOC.	COMP.	LOC.
C1	H 3	D1	F 3	K605	C 2	R17	H 3	R313	G 3	R609	F 2
C2	H 3	D2	F 4	K606	B 5	R18	H 3	R314	G 3	R610	F 2
C3	H 3	D3	F 3	K607	B 5	R19	H 3	R315	G 2	R611	H 4
C4	H 3	D4	F 4			R20	H 3	R316	G 3	R612	H 4
C5	H 3	D5	F 3	J	B 2	R21	H 2	R317	G 3	R613	H 4
C6	H 3	D6	F 4	J	B 3	R22	H 2	R318	G 3	R614	H 5
C7	H 2	D200	F 4	J206	B 5	R23	H 2	R319	G 3	R615	H 4
C8	H 2	D202	H 3	J200	C 2	R24	G 3	R380	G 3	R616	H 4
C9	F 4	D203	H 3	J203	B 5	R25	H 2	R381	G 2	R617	H 5
C10	F 3	D204	F 4	J207	D 5	R26	H 2	R382	G 2	R618	H 5
C11	F 3	D220	H 4	J235	D 5	R27	F 4	R383	G 2	R619	H 5
C12	F 3	D221	H 4	J250	D 4	R28	F 4	R384	G 2	R620	G 4
C13	G 4	D250	G 3	J259	B 2	R29	F 4	R385	G 2	R621	G 4
C14	F 2	D251	G 3	J253	B 2	R30	F 4	R386	G 2	R622	G 4
C15	D 2	D252	G 2	J350	D 4	R32	F 4	R394	G 4	R623	G 5
C16	D 2	D253	G 2	J391	B 2	R33	F 3	R395	G 4	R624	G 5
C17	D 2	D254	C 3	J400	D 4	R34	F 3	R396	G 4	R625	H 5
C132	G 4	D255	G 2	J401	D 5	R35	F 4	R397	G 3	R626	H 5
C80	B 4	D256	G 2	J402	D 5	R36	F 4	R400	F 4	R627	H 5
C81	G 4	D257	G 2	J403	D 5	R37	F 4	R401	F 4	R628	H 5
C52	G 4	D258	G 2	J404	D 5	R38	F 3	R402	F 5	R629	H 5
C53	G 4	D260	C 4	J405	D 4	R39	F 3	R403	F 4	R630	H 5
C54	G 4	D261	G 4	J406	D 4	R40	E 4	R404	F 4	R631	H 5
C85	G 4	D300	F 4	J407	D 4	R41	F 4	R405	F 4	R632	H 5
C56	G 4	D302	H 3	J408	D 4	R42	F 4	R406	F 4	R633	H 5
C57	G 4	D303	H 3	J409	D 4	R43	F 4	R407	F 4	R634	H 5
C201	F 4	D350	G 3	J40	D 4	R44	E 4	R408	H 3	R635	H 5
C202	C 4	D351	G 3	J41	D 4	R45	E 4	R409	H 3	R636	H 5
C203	G 4	D352	G 2	J42	D 4	R46	E 4	R420	H 3	R637	H 5
C220	D 4	D353	G 2	J43	D 4	R47	E 3	R421	H 4	R638	H 5
C221	F 4	D354	C 3	J450	D 4	R48	E 3	R422	H 4	R639	H 4
C222	D 4	D355	G 2	J451	B 2	R49	E 3	R423	H 4	R640	H 5
C223	D 4	D356	G 2	J452	D 3	R50	F 3	R424	H 4	R641	F 5
C224	D 4	D357	G 2	J500	D 5	R51	E 3	R425	G 4	R642	G 5
C225	F 4	D358	G 2	J501	D 5	R52	E 3	R426	F 4	R643	F 5
C226	D 4	D360	C 4	J503	D 5	R53	E 3	R427	F 5	R650	H 5
C227	D 5	D361	G 4	J504	C 5	R54	E 3	R428	H 4	R652	G 2
C228	E 4	D400	F 5	J505	C 5	R55	E 3	R429	H 4	R653	F 2
C229	F 5	D402	H 3	J506	C 5	R56	E 3	R450	G 4	R654	G 2
C230	D 5	D403	H 3	J509	D 2	R57	F 3	R451	G 4	R655	G 5
C250	G 4	D420	H 3	J560	D 2	R58	E 3	R452	G 4	R656	G 5
C251	G 4	D421	H 3	J570	D 2	R59	E 3	R453	F 4	R700	H 3
C252	G 4	D450	G 3	J580	D 2	R60	E 3	R454	F 4	R701	H 3
C253	B 3	D451	G 3	J600	D 4	R61	F 3	R455	G 4	R720	H 5
C254	G 3	D452	G 2	J701	B 4	R62	E 3	R456	F 4	R721	G 5
C255	G 3	D453	G 2	J703	B 4	R63	E 3	R457	G 4	R722	H 5
C256	G 3	D454	D 3	J734	B 3	R64	F 3	R458	G 4	R723	G 5
C257	B 3	D455	F 2	J735	B 4	R65	F 3	R459	G 4	R740	H 5
C258	G 3	D456	F 2	J736	B 4	R66	F 3	R460	F 3	R767	F 3
C259	G 2	D457	F 2	J74	C 2	R67	F 3	R461	G 3	R773	F 3
C260	H 3	D458	F 2	J744	B 4	R68	G 4	R462	G 3	R776	F 3
C261	G 3	D459	D 3	J746	B 3	R69	G 4	R463	G 3	R778	H 5
C262	G 4	D460	C 4	J757	D 3	R70	F 4	R464	G 3	R782	H 5
C267	C 3	D461	F 4	J759	D 3	R71	F 4	R465	F 3	R783	F 3
C270	G 4	D500	F 5	J760	D 3	R72	F 4	R466	G 3	R785	F 4
C271	D 4	D501	F 5	J764	B 3	R73	F 4	R467	G 3	R786	F 4
C272	D 4	D502	F 5	J765	B 3	R74	F 4	R468	G 3		
C300	G 4	D503	F 5	J766	B 2	R75	F 4	R469	F 3	SR2	C 2
C301	G 4	D504	F 5	J778	D 3	R76	F 3	R470	F 3	SR3	C 2
C302	C 4	D505	F 5	J779	B 5	R77	F 2	R471	F 3	SR4	B 2
C303	G 4	D506	F 5	J780	B 3	R78	F 2	R472	F 3	SR5	C 2
C120	F 4	D507	F 5	J781	B 5	R79	F 2	R473	F 3		
C121	F 5	D508	F 5	J782	B 5	R80	F 2	R474	F 3	Z1	H 3
C322	D 5	D509	F 5	J793	B 5	R81	F 2	R475	F 2	Z2	F 3
C350	G 4	D580	F 5	J794	B 5	R82	F 2	R476	F 3	Z3	F 3
C381	G 4	D581	F 5			R84	F 4	R477	F 3	Z4	F 3
C382	G 4	D582	F 5	L50	C 4	R85	F 4	R478	G 3	Z50	G 2
C353	C 3	D513	F 5	L241	C 3	R86	G 4	R479	G 3	Z250	G 3
C354	G 3	D514	F 5	L242	C 3	R87	F 4	R480	F 3	Z350	G 3
C355	G 3	D515	F 5	L243	C 3	R88	F 4	R481	G 2	Z450	F 3
C356	G 3	D516	F 5	L601	C 2	R89	F 4	R482	F 2	Z500	H 3
C357	C 3	D517	G 5	L602	C 2	R90	H 3	R483	F 2	Z620	F 2
C358	G 3	D518	F 5	L603	C 2	R91	F 4	R484	F 2	Z621	D 2
C359	G 2	D519	F 5	L720	B 5	R92	F 4	R485	F 2	Z720	H 5
C360	G 3	D520	G 5			R90	G 4	R486	F 2		
C361	G 3	D521	G 5	P250	C 4	R91	G 3	R487	F 3		
C362	G 4	D522	G 5	P251	C 3	R92	G 4	R488	F 3		
C363	C 3	D523	G 5	P350	C 4	R93	G 4	R489	F 3		
C370	G 4	D524	G 5	P351	C 3	R200	G 4	R490	F 3		
C400	F 4	D525	G 5	P450	C 4	R201	F 4	R491	F 3		
C401	G 4	D526	G 5	P451	C 3	R202	F 4	R492	F 3		
C402	C 4	D527	G 5			R203	G 4	R493	G 4		
C403	G 4	D528	G 5	D1	H 3	R204	G 4	R494	G 4		
C420	H 4	D529	G 5	D2	F 4	R205	G 4	R495	G 4		
C421	G 4	D530	G 5	D3	F 3	R206	G 4	R496	G 4		
C422	G 4	D531	G 5	D4	F 3	R207	F 4	R497	F 3		
C423	G 4	D532	G 5	D5	F 3	R208	H 3	R500	F 5		
C424	H 4	D533	G 5	D6	E 3	R209	H 3	R501	F 5		
C450	G 4	D534	G 5	D7	E 3	R220	F 4	R502	F 5		
C451	F 4	D535	F 4	D8	E 2	R221	F 4	R503	F 5		
C452	G 4	D536	G 4	D9	F 2	R222	F 4	R504	F 5		
C453	C 3	D537	G 4	D10	E 2	R223	F 4	R505	F 5		
C454	G 3	D538	H 5	D23	H 3	R224	F 4	R506	F 5		
C455	F 3	D539	F 5	D200	F 4	R225	F 4	R507	F 5		
C456	F 3	D540	F 5	D201	G 4	R226	F 4	R508	F 5		
C457	C 3	D541	F 5	D202	F 4	R227	F 4	R509	F 5		
C458	G 3	D542	F 4	D220	F 4	R228	F 4	R510	F 5		
C459	G 2	D600	H 4	D221	F 4	R229	F 4	R511	F 5		
C460	G 3	D601	H 4	D222	F 4	R230	F 4	R512	F 5		
C461	F 3	D602	H 3	D223	F 4	R231	E 4	R513	F 5		
C462	D 3	D603	H 3	D224	F 5	R232	F 4	R514	F 5		
C463	F 3	D604	H 4	D225	F 4	R233	F 5	R515	F 5		
C464	F 3	D605	H 4	D226	G 3	R234	E 4	R516	F 5		
C465	F 3	D606	H 4	D227	G 3	R235	F 5	R517	F 5		
C466	G 4	D607	H 4	D228	G 3	R236	F 4	R518	F 5		
C467	C 3	D608	H 4	D229	G 3	R237	F 4	R519	F 5		
C470	G 4	D609	H 2	D230	G 3	R238	E 4	R520	F 5		
C500	D 5	D610	F 3	D231	G 3	R239	F 5	R521	F 5		
C501	D 5	D611	B 4	D232	G 3	R240	F 5	R522	F 5		
C502	F 5	D612	B 4	D233	G 3	R241	F 5	R523	F 5		
C503	F 5	D613	B 4	D234	G 3	R242	F 5	R524	F 5		
C504	F 5	D614	B 4	D235	G 3	R243	F 5	R525	F 5		
C505	F 5	D615	B 4	D236	G 3	R244	E 5	R526	F 5		
C506	D 5	D616	H 5	D237	G 3	R245	F 4	R527	F 5		
C507	D 5	D617	H 5	D238	G 3	R246	G 4	R528	F 5		
C508	E 5	D618	H 5	D239	G 3	R247	G 4	R529	F 5		
C509	E 5	D619	H 4	D240	G 3	R248	G 4	R530	F 5		
C510	F 5	D620	H 4	D241	G 3	R249	G 4	R531	F 5		
C511	D 5	D621	H 4	D242	G 3	R250	G 4	R532	F 5		
C512	D 5	D622	B 4	D243	G 3	R251	G 4	R533	F 5		
C513	F 5	D623	B 4	D244	G 3	R252	G 4	R534	F 5		
C514	F 5	D624	B 4	D245	G 3	R253	G 4	R535	F 5		
C515	F 5	D625	G 5	D246	G 3	R254	G 4	R536	F 5		
C516	C 5	D626	C 5	D247	G 3	R255	G 4	R537	F 5		
C517	D 5	D627	H 5	D248	G 3	R256	G 4	R538	F 5		
C518	F 5	D628	H 5	D249	G 3	R257	G 4	R539	F 5		
C519	F 5	D629	H 5	D250	G 3	R258	G 4	R540	F 5		
C520	F 5	D630	H 5	D251	G 3	R259	G 4	R541	F 5		
C521	G 5	D631	H 4	D252	G 3	R260	G 3	R542	F 5		
C522	G 5	D632	H 4	D253	G 3	R261	G 3	R543	F 5		
C523	G 5	D633	H 4	D254	G 3	R262	G 3	R544	F 5		
C524	C 5	D634	H 5	D255	G 3	R263	G 3	R545	F 5		
C525	C 5	D635	H 5	D256	G 3	R264	G 3	R546	F 5		
C526	G 5	D636	H 5	D257	G 3	R265	G 3	R547	G 5		
C527	G 5	D637	H 5	D258	G 3	R266	G 3	R548	G 5		
C528	G 5	D638	H 5	D259	G 3	R267	G 3	R549	G 5		



From FOCUS + SHIFT UNIT + G2 MODULE (J10)

From CONTRAST MODULATION (J1)

From BCL LINK UNIT (J1)

From SMPS MODULE (J10)

To IR RECEIVER FRONT (J780)

From CONTROLLER (J3)



From CONTROLLER (J2)

To SYNC (J3)

To SYNC (J1)

To IR REC. & RS232 (J713)



Name	RGB INPUT + DRIVER	Article nr.	76 2228-1
Date	26-04-1995	Drawn	JVDY
		Checked	PDG
BARCO PROJECTION SYSTEMS			




To DECODER (J800)


To DECODER (J800)

# Blockdiagram RGB Drive





# Blockdiagram ABL control loop



REFERENCE NUMBERS : 500... 599

REFERENCE NUMBERS : 500... 599

INTERNAL  
COMPOSITE  
SYNC

CS\_CTRL  
>SHEET6  
>J3[5]

## VIDEO

S-VIDEO

GBS

1

SYNC\_IN

RGsE

S-VID REAR PANE

J235 5  
J235 6 MO  
J235 7 HO  
J235 8 S-  
J235 9 CO

```
>SHEET2
VID_select
```

>SHEET2  
S-VID\_selec-

```
>SHEET2
sync_detect
```

> SHEET2  
B\_select

+12


VIDEO  
INPUT  
1 Ypp

LUMINANCE  
INPUT  
1 Vpp


CHROMINANCE  
INPUT  
0.28 V<sub>pp</sub>

INPUT  
COMP SYNC  
1-4 V<sub>DD</sub>


INPUT  
RED / (R-Y)  
0.7V<sub>pp</sub>



REFERENCE NUMBERS 600... 699



COMPONENTS MARKED WITH \* OR  $\Delta$  HAVE SPECIAL CHARACTERISTICS IMPORTANT TO SAFETY. BEFORE REPLACING ANY OF THESE COMPONENTS, READ CAREFULLY THE SERVICE SAFETY PRECAUTIONS. DO NOT DEGRADE THE SAFETY OF THIS SET THROUGH IMPROPER SERVICING.





Modifications reserved

Name RGB INPUT + DRIVER		Article nr. 76 2228-1
Date 09-03-1995	Drawn JVDY	Checked PDG


BARCO PROJECTION SYSTEMS









Name RGB INPUT + DRIVER		Article nr. 76 2228-1
Date 13-03-1995	Drawn JVDY	Checked PDG
BARCO PROJECTION SYSTEMS		














Name	RGB INPUT + DRIVER	Article nr.	76 2228-1
Date	24-04-1995	Drawn	JVDY
		Checked	PDG
BARCO PROJECTION SYSTEMS			



REFERENCE NUMBERS : 700... 799


Name RGB INPUT + DRIVER		Article nr. 76 2228-1
Date 07-03-1995	Drawn JVDY	Checked PDG

BARCO PROJECTION SYSTEMS


A			B			C			D			E			F			G			H			BARCO					
COMP.	LOC.	SHEET	COMP.	LOC.	SHEET	COMP.	LOC.	SHEET	COMP.	LOC.	SHEET	COMP.	LOC.	SHEET	COMP.	LOC.	SHEET	COMP.	LOC.	SHEET	COMP.	LOC.	SHEET						
C1	A	5	C504	B	6	D354	I	4	D774	B	2	IC600	I	5	Q23	E	6	R30	K	4	R263	F	2	R458	D	4	R576	K	5
C2	B	6	C505	B	6	D355	K	3	D775	B	4	IC601	D	6	Q200	A	3	R31	K	4	R264	G	2	R459	D	3	R577	K	5
C3	B	6	C506	B	5	D356	L	3	D777	B	4	IC601	E	5	Q201	G	1	R32	L	4	R265	G	2	R460	F	5	R578	L	5
C4	D	5	C507	C	5	D357	L	3	D780	C	5	IC601	E	5	Q202	I	4	R33	K	5	R266	G	1	R461	F	5	R579	L	5
C5	A	4	C508	C	5	D358	L	3	D781	C	5	IC601	E	6	Q220	G	5	R34	K	5	R267	G	1	R462	F	5	R580	K	4
C6	C	4	C509	D	6	D360	C	2	D782	C	5	IC601	E	6	Q221	F	6	R35	L	5	R268	G	2	R463	F	5	R581	K	4
C7	D	3	C510	D	6	D361	D	2	D783	C	5	IC601	G	6	Q222	F	5	R36	J	6	R269	G	2	R464	G	5	R582	K	4
C8	K	6	C511	D	6	D400	A	3	IC1	C	4	IC601	H	5	Q223	E	5	R37	J	6	R270	G	2	R465	G	5	R583	K	2
C9	K	6	C512	D	6	D402	H	3	IC2	C	4	IC602	B	1	Q224	C	6	R38	F	1	R271	H	2	R466	G	5	R584	K	2
C10	H	6	C513	D	6	D403	H	3	IC2	B	4	IC603	B	2	Q250	D	2	R39	F	1	R272	H	2	R467	G	5	R585	K	2
C11	H	5	C514	D	6	D420	H	6	IC2	C	4	IC604	B	2	Q251	F	1	R40	F	3	R273	H	2	R468	G	5	R586	K	3
C12	H	5	C515	D	6	D421	H	6	IC2	C	4	IC605	B	3	Q252	G	1	R41	F	3	R274	I	2	R469	G	5	R587	L	3
C13	I	4	C516	D	6	D450	G	5	IC2	B	6	IC606	B	6	Q253	G	1	R42	F	5	R275	I	2	R470	G	6	R588	D	1
C14	A	2	C517	G	6	D451	G	5	IC2	C	6	IC606	C	5	Q254	G	2	R43	F	5	R276	I	2	R471	H	5	R589	D	1
C15	A	3	C518	G	6	D452	I	5	IC2	D	4	IC607	A	4	Q255	G	2	R44	I	1	R277	I	2	R472	H	6	R590	C	1
C16	A	3	C519	G	6	D453	I	5	IC2	E	5	J1	D	1	Q256	L	1	R45	I	1	R278	I	1	R473	H	6	R591	G	2
C17	A	1	C520	G	6	D454	I	5	IC2	E	1	J3	D	1	Q300	B	3	R46	I	1	R279	J	1	R474	I	6	R592	G	2
C18	G	3	C521	I	6	D455	K	5	IC3	D	5	J206	G	3	Q301	F	1	R47	I	2	R280	J	2	R475	I	6	R593	G	2
C19	G	4	C522	I	6	D456	L	5	IC3	C	6	J210	C	1	Q302	I	4	R48	I	2	R281	J	1	R476	I	6	R594	F	2
C132	B	2	C523	I	6	D457	L	5	IC3	D	3	J213	E	5	Q350	D	3	R49	I	2	R282	K	1	R477	I	6	R595	F	2
C150	C	2	C524	I	6	D458	L	5	IC3	D	3	J215	E	5	Q351	F	3	R50	I	1	R283	K	2	R478	I	5	R596	F	1
C151	C	2	C525	H	4	D459	F	5	IC3	E	2	J217	F	6	Q352	G	3	R51	J	1	R284	L	1	R479	J	5	R597	F	2
C152	A	4	C526	H	4	D460	D	2	IC3	E	3	J217	G	6	Q353	G	3	R52	J	1	R285	L	2	R480	J	5	R598	C	2
C153	A	4	C527	H	4	D461	D	2	IC3	E	3	J217	G	6	Q354	G	4	R53	J	1	R286	L	1	R481	J	5	R599	C	2
C154	A	4	C528	H	4	D500	A	3	IC4	L	5	J217	I	6	Q355	G	4	R54	J	2	R287	L	1	R482	K	5	R600	A	2
C155	C	2	C529	H	4	D501	A	3	IC4	L	4	J217	K	6	Q356	L	3	R55	J	2	R288	L	1	R483	K	6	R601	G	5
C156	C	2	C530	J	6	D502	A	3	IC4	L	4	J235	H	3	Q400	B	3	R56	J	2	R289	L	1	R484	L	6	R602	G	5
C157	A	5	C531	J	6	D503	A	3	IC4	L	5	J235	H	3	Q401	E	1	R57	J	1	R290	L	1	R485	L	6	R603	G	4
C201	L	4	C532	J	6	D504	B	2	IC5	C	2	J235	H	2	Q402	I	5	R58	K	1	R291	E	2	R486	L	5	R604	F	1
C202	L	4	C533	J	6	D505	B	2	IC5	C	2	J235	H	2	Q420	K	6	R59	K	1	R292	E	2	R487	F	5	R605	G	6
C203	L	4	C534	J	6	D506	B	2	IC5	C	2	J235	H	2	Q421	K	6	R60	K	1	R293	E	2	R488	E	5	R606	G	2
C220	E	6	C535	J	6	D507	B	2	IC5	C	2	J235	H	2	Q450	D	3	R61	K	2	R294	E	2	R489	E	5	R607	J	4
C221	E	6	C536	J	6	D508	C	3	IC5	C	2	J235	H	2	Q451	F	5	R62	K	2	R295	E	2	R490	E	6	R608	J	5
C222	E	6	C537	J	6	D509	C	3	IC5	C	2	J235	H	2	Q452	G	5	R63	K	2	R296	E	2	R491	E	6	R609	J	5
C223	E	6	C538	J	6	D510	C	3	IC6	G	1	J253	D	2	Q453	G	5	R64	L	1	R297	E	2	R492	E	6	R610	J	4
C224	B	4	C539	K	5	D511	C	4	IC7	G	3	J350	C	3	Q454	G	6	R65	H	6	R300	E	1	R493	G	6	R611	J	3
C225	B	4	C540	L	6	D512	D	4	IC8	G	5	J351	H	3	Q455	G	6	R66	H	6	R301	E	1	R494	B	4	R612	J	3
C226	B	4	C541	L	6	D513	D	4	IC9	H	2	J400	C	2	Q456	L	5	R67	H	6	R302	E	1	R495	C	2	R613	I	3
C227	C	6	C542	K	5	D514	E	4	IC9	H	2	J401	D	3	Q457	F	6	R68	I	4	R303	E	1	R496	D	2	R614	I	3
C228	E	6	C543	K	5	D515	E	4	IC9	H	2	J402	E	3	Q500	A	4	R69	I	4	R304	E	1	R497	E	6	R615	G	3
C229	B	4	C544	K	5	D516	F	4	IC9	H	2	J403	E	4	Q501	A	4	R70	H	4	R305	E	1	R498	E	6	R616	G	3
C230	B	4	C545	K	5	D517	F	4	IC9	H	2	J404	E	4	Q502	A	4	R71	H	4	R306	E	1	R499	E	6	R617	F	3
C231	E	6	C546	K	5	D518	F	4	IC13	A	2	J405	C	3	Q503	C	4	R72	I	5	R307	E	1	R500	A	6	R618	E	3
C250	A	3	C547	G	2	D519	G	3	IC200	H	4	J406	E	3	Q504	C	4	R73	I	5	R308	E	1	R501	A	5	R619	I	1
C251	C	2	C548	G	2	D520	C	2	IC201	K	4	J407	E	3	Q505	C	4	R74	H	6	R309	E	1	R502	A	5	R620	H	1
C252	D	2	C549	G	2	D521	F	2	IC202	J	1	J408	E	3	Q506	D	4	R75	H	5	R310	E	1	R503	A	5	R621	H	1
C253	F	1	C550	F	2	D522	G	3	IC202	J	1	J409	E	3	Q507	D	4	R76	A	1	R311	E	1	R504	B	5	R622	G	2
C254	F	1	C551	G	3	D523	H	4	IC202	J	1	J410	E	3	Q508	D	4	R77	A	2	R312	E	1	R505	B	5	R623	G	2
C255	G	2	C552	G	3	D524	H	4	IC202	J	1	J411	E	3	Q509	F	4	R78	A	2	R313	E	1	R506	B	5	R624	G	2
C256	E	2	C553	G	3	D525	H	4	IC202	J	1	J412	E	3	Q510	F	4	R79	A	2	R314	E	1	R507	B	5	R625	G	2
C257	I	1	C554	K	4	D526	I	3	IC202	J	1	J413	E	3	Q511	F	4	R80	A	3	R315	E	1	R508	B	5	R626	G	2
C258	J	2	C555	K	4	D527	I	3	IC202	J	1	J414	E	3	Q512	H	4	R81	B	1	R316	E	1	R509	A	4	R627	F	2
C259	J	1	C556	K	4	D528	J	4	IC203	J	2	J415	H	5	Q513	H	4	R82	A	1	R317	E	1	R510	A	4	R628	F	2
C260	K	2	C557	K	4	D529	J	4	IC203	J	2	J416	H	5	Q514	H	4	R83	A	2	R318	E	1	R511	A	4	R629	F	2
C261	L	2	C558	K	4	D530	K	3	IC203	J	3	J452	F	6	Q515	I	4	R84	B	2	R319	E	1	R512	C	3	R630	E	1
C262	C	4	C559	K	4	D531	K	3	IC203	J	3	J500	B	6	Q516	I	4	R85	B	3	R320	E	1	R513	C	3	R631	E	1
C263	G	2	C560	K	4	D532	K	3	IC203	J	3	J501	C	6	Q517	I	4	R86	C	3	R321	E	1	R514	C	3	R632	E	1
C264	G	2	C561	K	4	D533	L	3	IC203	J	3	J502	G	6	Q518	K	4	R87	L	5	R322	E	1	R515	C	3	R633	E	1
C265	G	2	C562	K	4	D534	L	3	IC220	L	1	J503	H	6	Q519	K	4	R88	K	5	R323	E	1	R516	C	3	R634	D	4
C266	C	4	C563	K	4	D535	L	3	IC220	L	1	J504	H	6	Q520	K	4	R89	K	5	R324	E	1	R517	C	3	R635	D	4
C267	G	2	C564	K	4	D536	L	3	IC220	L	1	J505	J	6	Q521	L	2	R90	D	5	R325	E	1	R518	C	3	R636	D	4
C268	G	2	C565	K	4	D537	L	3																					




Blockdiagram  
Support signals



Support signals








## Adjustment procedure for the RGB Input + Driver module

### Adjustments on the module:

- adjustment of the GAIN of the Pre-Amplifiers for Red (P250), Green (P350) and Blue (P450)
- adjustment of the GAIN of the output Amplifiers for Red (P251), Green (P351) and Blue (P451)


### Location of the controls



## Adjusting conditions

### Signal input:

- Connect a RGB signal (0.7Vpp Bl&Wh) to the projector and select the corresponding input (refer to the manuals of the projector).



### Contrast and Brightness setting (refer to the Owner's manual of the projector)

- adjust the Contrast level until the bar scale on the screen indicates 100.
- adjust the Brightness level until the bar scale on the screen indicates 50.

### GAIN adjustment For Red, Green and Blue (refer to the Owner's manual of the projector)

- Proceed to Random Access Adjustment mode and select the Picture tuning.
- Highlight *White Balance* with the arrow keys and press ENTER to display the White Balace menu.
- Proceed to *For Custom adjust*.
- *Adjust the GAIN for RED* until the bar scale on the screen indicates 50.
- *Adjust the GAIN for GREEN* until the bar scale on the screen indicates 50.
- *Adjust the GAIN for BLUE* until the bar scale on the screen indicates 100.

## Adjustment

**Attention: To eliminate Beam Current Limiting (BCL) while adjusting the GAIN potentiometers, remove the anode lead of the three picture tubes on the EHT Splitter.**


### WARNING

**The power must be OFF before removing any connector from EHT splitter. Failure to do so may result in DANGER TO LIFE and severe damage to the projection unit.**

Removing the anode lead of the three picture tubes

- switch OFF the projector and unplug the power cord from the power input on the front panel.
- unlock the anode lead cap by turning it counter clockwise.
- pull out, by the cap, the anode lead for each picture tube from the EHT splitter and discharge the picture tube anode by touching the top of the lead to the aquadag grounding shield.
- reinstall Power connection and switch ON the projector.

e.g. Removing the anode lead of the Blue picture tube



## Adjustment of the RED channel

### Pre-amplifier P250

- connect the probe of the oscilloscope to the testpoint TP200.
- Adjust the potentiometer P250 for a video signal amplitude of 4V (refer to fig.)
- (the black level is at about 2V DC)




Fig. 1

### Output Amplifier P251

- connect the probe of the oscilloscope to the testpoint TP201.
- Adjust the potentiometer P251 for a video signal amplitude of 4V (refer to fig.)




Fig. 2

## Adjustment of the GREEN channel

### Pre-amplifier P350

- connect the probe of the oscilloscope to the testpoint TP300.
- Adjust the potentiometer P350 for a video signal amplitude of 4V (refer to fig.1)
- (the black level is at about 2V DC)

### Output Amplifier P351

- connect the probe of the oscilloscope to the testpoint TP301.
- Adjust the potentiometer P351 for a video signal amplitude of 4V (refer to fig.2)


## Adjustment of the BLUE channel

### Pre-amplifier P450

- connect the probe of the oscilloscope to the testpoint T400.
- Adjust the potentiometer P450 for a video signal amplitude of 4V (refer to fig.1)
- (the black level is at about 2V DC)

### Output Amplifier P451

- connect the probe of the oscilloscope to the testpoint TP401.
- short-circuit the two pins of the connector J452.
- Adjust the potentiometer P451 for a video signal amplitude of 4V (refer to fig.2)




## Adjustment procedure for the RGB Output

**Attention:** To eliminate Beam Current Limiting (BCL) while adjusting the GAIN and CUT OFF potentiometers, remove the anode lead of the three picture tubes on the EHT Splitter (see page 8 for procedure 'anode lead removal').


## Adjustment of the input signal

- connect the probe of the oscilloscope to pin 2 of the connector J1 on the output module.
- adjust Contrast and Brightness levels by means of the RCU or the local keypad for an input signal with amplitude of 2.35V and a the black level on 1.7V





## Location of the controls

remove the plastic cover to access the controls



## Adjustments

- connect the probe of the oscilloscope to the cathode of the respective picture tube (resistor R25).
- Adjust the potentiometer P1 for a video signal amplitude of 100V and the potentiometer P2 for a DC level of 185V (refer to fig.)
- As both adjustments affect each other, repeat the adjustment of both potentiometers.
- Repeat the adjustment procedure for each picture tube.





## End of the adjustments

At the end of the adjustment procedure, reinsert the anode lead of each picture tube and remove the short circuit on connector J452. Proceed as follows:

### Inserting the anode lead of each picture tube


#### WARNING

**The power must be OFF before inserting any connector on the EHT splitter. Failure to do so may result in DANGER TO LIFE and severe damage to the projection unit.**


e.g. Inserting the anode lead of the Blue picture tube

Inserting the anode lead of the three picture tubes


- switch OFF the projector and unplug the power cord from the power input on the front panel.
- insert the anode lead of each picture tube into the EHT splitter.
- lock the anode lead cap by turning it clockwise.
- reinstall Power connection and switch ON the projector.



### Removing the short circuit on connector J452



Control LED's on the module



*\* For the G2-Adjustment, refer to the service sheet 'Shift+Focus module 762488'*

## TECHNICAL DESCRIPTION "SIGNAL INPUT "

### Introduction

The projector can operate in one of the following modes by pushing the corresponding numeric button or by means of the identification of the input board of a switcher RCVS800 or RCVDS05 :

- 1) Video composite
- 2) Super Video (SVHS)
- 3) RGB Analog level (automatically switching between Sync on Green and Separate Sync, with priority on Separate Sync).
- 4) Component input : Y, R-Y, B-Y with Bi-level sync
- 5) RGB analog level with Tri-Level Sync (HDTV)
- 6) Component input : Y, R-Y, B-Y with Tri-level sync (HDTV).

The selection between the standard BI-level sync and the HDTV TRI-level is NOT automatic but is done by the selection of the corresponding input.

The selection of the sync signal between RGBS and RGsB however is automatic and there is always priority for the separate sync if both are applied.

### Input selection

The different signals are selected by means of 7 current generators activating each time a differential input. All of these 7 inputs are switchable between non-differential or differential , but, are factory set for non-differential.

The electronic circuit comprises different sheets. On sheet 2 the selection voltages are generated by a BCD/DEC decoder which is directed from a BCD coded info using three output ports of the I<sup>2</sup>C interface. The spot suppression circuit and the combined blanking is also represented on this sheet.

Sheet 1 is purely representing the signal input amplifiers.

#### A. Mode Selection .

The I<sup>2</sup>C Interface PCF8574A output ports P7 - P5 are connected to IC606 inputs. The respective output of the Decoder IC drives one or more switching transistors on.

Five switching voltages have to be generated. These switching voltages activate an input amplifier, switch the correct brightness pulse etc...

Six green diodes supply a visual indication of the status of these switching voltages as a kind of service information.

Hereafter we discuss the different modes in more detail.

#### B. Composite video .

The output pin 1 of the BCD/DEC decoder goes low and turns on Q630 and Q629 to provide the *VID\_select* voltage. This voltage selects the video composite input by activating Q501/Q502 .

The same +VID voltage also must switch high the *MATRIX* line through D621 since the MUXDMUX needs to select the matrixed RGB signal (see sheet 3).

The video is now passed on to Q527 and the connector J401 for synchronisation. This connector is wired pin to pin with J402 if no module is inserted between the connectors, and the sync is now referred to as *SYNC\_SD* to be applied to the SYNC module.

The same video signal is also applied to Q524 and further proceeds to the DECODER module (LUMA/VID line).

The decoder module will be handled separately, as it is a different module. The output of this module is a component signal  $Y / (R-Y) / (B-Y)$  and returns to the input module on connector J401 (same connector of *SYNC\_EXT*).

Note that these signals are accompanied by a DC voltage which must forward bias the serial diodes D200, D300 and D400.

The component signals *(R-Y)\_DEC*, *Y\_DEC* and *(B-Y)\_DEC* from the decoder are now matrixed and the chrominance is adjusted in amplitude (saturation control) and they proceed then to the MUXDMUX IC200 (see sheet 3). Because the MATRIX line is high this IC200 selects these R/G/B signals for further processing.

## **C. S-VHS input.**

Output "1" or pin 2 of the BCD/DEC switches low and turns on Q628/Q627. The S-VID\_select voltage comes high and via some diodes the +VID and +MATRIX lines both come high as well. In this case three lines are high.

The luminance input is selected by the input amplifier and flows through the same circuit as if it were video.

The chrominance input is sent straight to the DECODER module via Q523.

## **D. RGB Analog input with standard BI-level sync.**

In this case output 3 of the BCD/DEC is switched low and turns on Q623 and Q622. Via D625 the emitter of Q624 is provided with the same voltage. However, conduction of the latter will be determined by the base voltage. This base voltage is the result of the automatic sync detector.

### **Automatic sync detection :**

The input transistor Q511 (sheet 1) supplies the separate sync (S input) to the *sync\_detect* line. This sync is amplified in Q626 (sheet 2). When no sync is applied Q625 remains in the blocked state and the base divider R620/R621/R622 drops the base voltage below the emitter and Q624 is turned on to provide the *RGsB\_select* voltage.

A similar explanation applies in case separate sync is applied.

If *RGsB* is high Q526 is forward biased delivers the Green signal to the *SYNC\_EXT* line. In this case D520 is blocked via D521. If separate sync is detected, it passes via D520 to Q527.

The R, G and B analog signals are selected by the three inputs and proceed now to the MUXDMUX IC200 (sheet 3) via three current drivers Q201, Q301 and Q401. Since the +MATRIX line is low here, these signals are selected by the MUXDMUX and are further handled as will be described later.

## **E. RGB Analog with TRI-level sync (HDTV).**

In this case output 4 or pin 3 is switched to a low level. Via D628 the *RGB\_select* voltage becomes high and via D646 transistor Q631 is fully on to pull the */HDTV* line at a low level (active low !).

The RGB signal is passing exactly the same flow as described above. The sync signal however is now passing the HDTV or TRI-level electronic circuit on the SYNC module. This will be discussed in more detail in the description of this board.

## **F. Component input (Y / R-Y / B-Y).**

The Y-signal must be connected to the G - input, the R-Y and B-Y to the respective R and B inputs of the projector.

Here, two lines must be high level : the *MATRIX* and *RGB\_select* lines.

Output 5 or pin 4 is switched low and via D629 the *RGB\_select* voltage can be generated same as described before.

Via D645 transistor Q632 is blocked and this turns on Q634 to light up the green *COMP VID* LED and put at a high level the *+MATRIX* line.

Most likely the sync is on the Y signal, the projector must then be switched to the RGsB mode. In the unlikely event that the sync is separate, the projector will switch to the RGBS mode by priority.

The three signals arrive at the bases of Q200, Q300 and Q400 (sheet 3). The DC level of these signals block the diodes D200/D300/D400 and pass now to the matrix / saturation circuit. Since the *MATRIX* line is high, the matrixed R, G and B signals are selected by the MUXDMUX IC200.

## **G. Component HDTV or TRI-Level Sync input.**

In this case three lines must be active : the */HDTV*, *MATRIX* and *RGB\_select*.

Output 6, or pin 5 is switched low level. Via D547 the *RGB\_select* voltage is generated. D644 turns on Q631 to pull the */HDTV* line at a low level. Finally, D643 blocks Q632 and the *MATRIX* line is put at a high level.

The component signals are handled just like described in paragraph F but the sync is here passing through the TRI - level sync circuit.

## **Blanking - Spot Suppression.**

The preparation of the total blanking information for the video amplifiers on the CRT sockets is finalised on this board.

The composite blanking (*COMP BLANKING*) is here combined with SF3 (Scan Fail), ABL (Automatic Black Level), and the software blanking.

The *COMP BLANKING* is composed of the flyback blankings, the user adjusted left/right and top/bottom blankings and the coincidence information. The composition of this signal will be discussed in the SYNC module description.

The output ports P0, P1 and P2 can be switched at a high level via I<sup>2</sup>C. The high output level of this I<sup>2</sup>C interface output is cancelled by the ABL pulse output pin 2 of IC601 as we need to unblank during the ABL measurement time.

This is necessary not to disturb the black current measurement during this measuring time.

The composite blanking must also be cancelled during this time and this is realised with D600, a diode connected from the ABL pulse output to the composite sync input. In case of a scan fail, the SF3 line is switched low, the Schmidt trigger output is then high (pin 4 of IC601) and all the blanking outputs are high. It does not matter in this situation that the black current measurement is wrong, as there is no EHT.

## Spot Suppression :

The spot suppression circuit is built around Q620 / Q621 and senses the +17V and the +210V at the moment the projector is switched off.

Indeed, the moment the projector is turned off, the +17V drops very quickly whereas the +210V drops only slowly due to the heavier load on the +17V compared with the +210V.

For a correct +17V, the transistor Q620 is in saturation and cuts off Q621. The electrolytic capacitor C620 is loaded to the zener voltage of 150V.

At switching off, Q620 turns off very rapidly and Q621 is thereby turned on. The sudden drop of the collector voltage of the latter is coupled to the G1's as the capacitor cannot discharge so fast. This heavy negative G1 voltage means an efficient spot suppression.

## Notes :

a) An inaccurate alignment of the +17V (too low) can cause intermittent blanking by heavy loads (plain white pictures).

b) The spot suppression can only behave correctly on condition the two sensed voltages are present or correct at the moment of turning off the projector.

c) An incorrect alignment of the G2 voltages (too high) reduces the efficiency of the spot suppression.

The drop of the collector voltage of Q621 is also coupled to the Schmidt trigger input pin 3 (same as for the SF3) via diode D602 to cause an immediate blanking.

Finally, diode D603 applies this (*SPOT*) voltage to the gates of Q251, Q351, Q451 (see sheet 4) in order to turn black the picture tubes via the cathodes.

Two more switching functions are performed by the I<sup>2</sup>C interface IC607 :

- Fast / Slow : Especially in video on reproduction of video tapes, the fast mode is almost a must to avoid tearing of the picture.

- Blue in Green : this feature can only be set in the RGB mode, but is becoming obsolete since most computers already have blue in green or avoid blue characters.

**Matrix - Saturation control** The matrix - saturation is done by the circuit Q220 - Q224 and IC221 (TBA331) on sheet 3 of the diagrams.

The saturation voltage (*Saturation*) is delivered by the VO3 output of IC7 (sheet 5) and buffered by the OPAMP TL082. The colour difference signal is applied each time to the common emitter current source of two identical differential amplifiers. The outputs are then respectively mixed with the Y signal in Q220 and Q223. On the collectors of these transistors we find the Red and Blue signals. These are now applied to the MUXDMUX on the pins 3 and 13.

The G-Y is formed by adding via R225 and R226 the (R-Y) and (B-Y) signals and by adding the Y, the Green is obtained. This Green signal is also sent to pin 1 of the MUXDMUX.

## **Selection of the RGB signals - Clamping**

The MUXDMUX IC200 selects between the RGB Analog coming straight from the BNC inputs and the RGB which is the result of the matrix. This section is done by the selecting voltage "MATRIX" as described before.

The RGB analog signals can undergo an adjustable bandwidth limiting by using

varicap diodes on which a variable voltage  $BWL\_VR$  is applied.

This voltage is generated by IC8, and the range is adapted by an OPAMP in IC5. From some (minimum) threshold onwards, the varicap diodes are fully isolated by switching diodes D261/D361/D461 driven by the  $BWL\_SWITCH$  voltage coming from the OPAMP output pin 7 of IC5. This must avoid any influence from the varicap diodes in the minimum position of the enhancing.

Bandwidth limiting is useful for improving the legibility of reversed characters (black characters on a white background).

The next MUXDMUX (IC201) has as task to select between the RGB signals and the text ( $R\_IN$ ,  $G\_IN$ ,  $B\_IN$ ) informations coming from the Controller board. This selection is done by the  $INSERT$  voltage accompanying the above pixel information.

In order to obtain the same brightness level, all the 6 available signals at the select inputs are clamped by a "CLAMP" pulse as follows.

The divider R320/R321 determines the clamping DC level which is then buffered and is available at the inputs of the six bilateral switches in IC202 and IC203. At the moment the CLAMP is presented the above DC level is implemented to the inputs and since this level is the same for all of the six possible signals, the text is correctly inserted irrelevant the fluctuations of the input signals.

The outputs of the MUXDMUX are referred to as  $R\_MUX$ ,  $G\_MUX$  and  $B\_MUX$  and proceed now to the contrast and brightness adjustments (see sheet 4). Since ABL is applied, some precautions and automatic corrections are necessary.

All these adjustments require pulses. The generation of these pulses will be discussed prior to the RGB flow and preparation for the video end amplifiers (sheet 5).

## K. Generation of the supporting pulses

### CLAMP pulse :

The position of this clamping pulse for the brightness control depends on the active mode of the projector. There are three different pulses available to determine the start of the brightness pulse (= leading edge). These pulses are :

- \* SC/CLAMP pulse
- \* CS\_INV
- \* HFB or BRT\_P1 pulse

a) The  $SC/CLAMP$  pulse is the Sandcastle pulse provided by the TDA2595 or a delayed  $CLAMP$  pulse to avoid clamping during the third sync level in HDTV.

b) The  $CS\_INV$  is the composite sync. The clamping pulse starts the moment the sync pulse is terminated (trailing edge of the positive sync pulse).

c) The  $BRT\_P1$  pulse is coincident with the flyback pulse. This means that the pulse position varies with the phase control. On other terms, the phase control has an influence on the clamping position and can affect the brightness.

When in the Sync on Green mode, the composite sync is selected to produce the clamping pulse and no sync is applied to the projector, there is no clamp pulse and the brightness control is in trouble. In fact, when there is no sync, the picture is blanked, but, the moment the sync is back it would take too long to settle down to



normal conditions. Therefore, the CS\_INV is replaced by the BRT\_P1 pulse when there is no coincidence in the Sync on Green mode.

For that reason, the COIN (coincidence) signal is sent to the base of Q1 and the latter pulls pin 1 at ground level. As then both switching pins are at low level, the BRT\_P1 pulse is selected in stead.

The CLAMP pulse is used to restore the black level of the signals before entering the MUXDMUX IC201 and for the brightness in the LM1203.

## **BRT\_P pulse :**

The negative HFB pulse is differentiated by C5/R15 in order to reduce the width to 2.1  $\mu$ S . These pulses are used to drive the Mosfets Q250/Q350/Q450 into cut-off and install a zero DC level at their Sources during the cut-off time (=inserting a brightness pulse for the preparation of the brightness control).

Note that the ABL pulse is added to this BRT\_P pulse via D5 in order to implement the black level during the ABL-time.

## **BRT\_P2 pulse :**

This is the same as BRT\_P but with opposite polarity, thus, a positive pulse of 2.1  $\mu$ S long.

Both these pulses are used to install the DC level of a brightness pulse with respect to the black level of the video signal.

Note that the ABL pulse of 20 $\mu$ S is added to both of these pulses. As will be described later the *Offsets* must be cancelled during the measurement time of the black level, otherwise the ABL receives a wrong information on the real black currents.

## **BRT\_P1 pulse :**

The BRT\_P pulse is once more differentiated by C8/R17 to reduce the width to 1.5  $\mu$ S . After inversion we get a positive BRT\_P1 pulse, smaller than the former pulses and used in the clamping circuits around IC251 / IC351 / IC451.

Note that these pulses are cancelled during the ABL time by applying the ABL pulse via D4 to the input of the inverter, pin 5.

## **ABL - ABL\_BL - ABL\_MP.**

An ABL pulse of 40 $\mu$ S, positioned at the end of the vertical flyback time, is generated on the DEFLECTION module.

This pulse is inverted by an inverter in IC3 and then differentiated by C7 / R22 to determine the width of the pulse that must be 20  $\mu$ S. The next inverter changes the polarity and generates the ABL\_BL pulse. This pulse determines the time of the leakage or black current measurement.

This positive pulse is once again differentiated by C8/R26 to generate in association with the inverter, another positive ABL\_MP pulse of the same width but this one is coming just behind the former one.

Indeed, during the total 40  $\mu$ S ABL time the first 20  $\mu$ S the leakage current is measured , followed by a window in which the result of a 10  $\mu$ A cathode current implementation is measured (see ABL description in the coming RGB DRIVE section).



**RGB Amplifier - Driver - ABL** The R, G and B signals are all three adjusted in amplitude and the DC level is varied by the respective contrast and brightness controls in the LM1203. These are the *general* contrast and brightness controls before the individual adjustments per colour are applied.

There are three identical circuits for Red, Green and Blue. We limit the description to the red channel. The Blue channel is slightly different as it has an additional gamma correction.

The black level of the video signal at the output of the LM1203 is determined by the brightness voltage. It is 2 volts for 50% brightness.

The divider R253/R256 reduces the video amplitude at the output of the LM1203 since it is too big to drive the amplifier EL2082.

Because an user's adjustable brightness and contrast control per colour is required to compensate the tolerances, the three signals will undergo now an adaptation of these levels.

## Gain control per colour :

The individual gain control is realized by means of an EL2082 (IC250 / IC350 / IC450). The waveforms for the optional contrast modulation are also applied to these gain control inputs, in combination with a DC level between 0 - 2 V for the individual gain controls.

## Black level control per colour :

An offset on the black levels (colour temperature adjustment) is obtained in two steps. In a first stage, a zero DC level is installed. In a second stage this level is altered (offset) by the user. In a third stage, a comparison-clamping circuit varies the DC level of the video in accordance with this offset. The ABL circuit has as task to stabilize this colour temperature in the time, or to correct the normal usage of the picture tubes.

Q250 is blocked during the BRT\_P pulse time and because the Source is then at ground level via R258, a 'brightness pulse' of zero volt is inserted in the video signal on the backporch. This zero level is also implemented during the ABL time, since the ABL pulse is added to the BRT\_P pulses via D5.

The signal passes then the amplifier IC250 and proceeds to the darlington Q252 / Q253.

The OFFSET\_R can shift this previously inserted level in a positive or negative sense as follows.

On sheet 5 we have the electronic diagram for the OFFSET\_R/G/B lines. The IC6 VO0 DC output level output is switched to the node R60/R61 during the BRT\_P2 pulse time and also during the ABL time. The ABL pulse is therefore added to the BRT\_P2 via D5 (see diagram BRT\_P2 generation, same sheet).

The current generator Q6/Q7 provides a variable current to the resistors R64 / D15 / D16 / R260 / R261. The drain voltage is consequently altered in a positive or negative sense in accordance with the named VO0 output. During the ABL\_MP time slot diode D9 gets blocked and an additional current flows through D15/D16 R64. This is the current that will be measured for the ABL control.

This divider is designed to implement a cathode voltage to all the three tubes which must result in a small 10  $\mu$ A current. The offset voltage however can change this implemented current. The measured current during the ABL\_MP (Measurement Period) time slot depends on the offset adjusted by the user.

This level will be stabilized in the time by a sample and hold circuit.

IC251 is a Norton amplifier. It compares the instant DC levels at the inputs the moment pin 5 is lifted up. This pin 5 is supplied with the BRT\_P1 pulses. When pin 5 is at a low level, the output is very high impendent.

Consequently, during the BRT\_P1 pulse time the instant DC level of the video is compared to the ABL voltage (=output of the analog switcher IC253). A correction and stabilisation of the DC level of the video signal is realized by the above looped circuit.

When the ABL voltage is switched off a resistive divider R272 / R273 guarantees a correct DC level output for the video signal.

Automatic Black Level (ABL) :

The automatic Black level is done in two steps : a leakage measurement, followed by a small current measurement.

### Leakage measurement

The cathode current flows through Q6 on the output module (see schematics of the video output amplifier - CRT socket) and is returned to the RGB drive module via pin 4 of the J1 connector as *ABL RED*. The voltage developed across R285 is applied to the non - inverting input of the OPAMP IC254. The gain of this OPAMP is determined by the feedback R282/R284. and the input is limited by two diodes.

The output of the OPAMP is sampled by the ABL\_BL pulse and hold on the capacitor C260. This voltage is integrated by the OPAMP and found at the output pin 7.

During the next time slot ABL\_MP, the voltage across R285 is the result of the output voltage pin 7 and the implemented small cathode current (10  $\mu$ A +or - the offset).

The output voltage at pin 8 of the OPAMP is sampled by the ABL\_MP pulse and hold on the capacitor C259.

The voltage range needs now to be adapted. Therefore, the voltage is buffered and shifted upwards by the next OPAMP amplifier. The initial voltage is set at 1.2V by the resistors R279 / R280. Two diodes limit here again the output voltage to avoid a drifting away of the amplifier.

When the ABL\_ON line is high, the voltage is applied to the inverting input of the Norton amplifier and used as the clamping voltage to adjust the DC level of the video. The ABL voltage can be switched off by software. The VO3 output of IC8 is used for this function (see sheet 5).

### G2 adjustment :

The correct behaviour of the ABL (on other terms, the implemented cathode current during the ABL\_MP time is really 10  $\mu$ A) is only guaranteed on condition the G2 voltages are correctly adjusted.

In the service menu, when activating the G2 ADJUST item, the special conditions to align the G2's are switched by software :

- internal pattern on 15 khz
- brightness and contrast at 50%
- no video (= black)

The developed ABL voltage under the above conditions is applied to two level detectors. Three resistors R274/275/276 determine a minimum and maximum voltage for the level detectors. Only when the ABL voltage is in the accepted zone, the LED is off and the G2 is correctly adjusted.

Note :

**The LEDs do not play any significant role in the normal operating modes. They can be on, off or go on and off depending on different parameters. Disregard the LEDs in the normal mode.**

Parts listing R762228

SIT.	ITEM NO.	DESCRIPTION	QUANTITY	SIT.	ITEM NO.	DESCRIPTION	QUANTITY
160	R133029	Q ACC ISO SET TO220	1	C256	P210122	C# X7R MU 100N K 50 1206	1
10	R133076	Q ACC ISO WSHR TO39	4	C257	R111678	C EL BRA 10M M 25E2 85	1
20	R3133921	J MD JMP P 1 E1SN	6	C258	P210122	C# X7R MU 100N K 50 1206	1
8100	R348100	WU JUMP 0,6	6	C259	P210122	C# X7R MU 100N K 50 1206	1
	R3485154	CD CT FTMS P15 70	2	C260	P210092	C# X7R MU 10N K 50 1206	1
120	R3631049	SCR D933 M 3 X 6 XIC	6	C261	P210148	C# Y5V MU 470N Z 50 1206	1
130	R3631069	SCR D933 M 3 X 10 XIC	1	C266	P210029	C# COG MU 2N2J 50 1206	1
150	R366102	NUT D934 M 3 S Z	1	C267	R111510	C EL RA 22M M 25E2 85	1
140	R367502	WSHR D6798 A 3.2 S Z	1	C270	P210076	C# COG MU 220P J 50 1206	1
30	R367600	NUT BLOC M 3	2	C271	R111510	C EL RA 22M M 25E2 85	1
100	R805375	HTSNK PJ53 V700 INP MK2	1	C272	R111678	C EL BRA 10M M 25E2 85	1
170	V3134911	J U0.3 FBT P 8 E1AU TLP	3	C300	P210008	C# COG MU 15P J 50 1206	1
C 1	P210122	C# X7R MU 100N K 50 1206	1	C301	P210122	C# X7R MU 100N K 50 1206	1
C 2	P210158	C# COG MU 150P J 50 1206	1	C302	R111678	C EL BRA 10M M 25E2 85	1
C 3	P210061	C# COG MU 4P7D 50 0805	1	C303	P210122	C# X7R MU 100N K 50 1206	1
C 4	P210101	C# COG MU 560P J 50 1206	1	C320	P210122	C# X7R MU 100N K 50 1206	1
C 5	P210101	C# COG MU 560P J 50 1206	1	C321	P210122	C# X7R MU 100N K 50 1206	1
C 6	P210006	C# COG MU 820P J 50 1206	1	C322	R111510	C EL RA 22M M 25E2 85	1
C 7	P210101	C# COG MU 560P J 50 1206	1	C350	P210122	C# X7R MU 100N K 50 1206	1
C 8	P210101	C# COG MU 560P J 50 1206	1	C351	P210010	C# COG MU 68P J 50 1206	1
C 9	P210122	C# X7R MU 100N K 50 1206	1	C352	P210236	C# COG MU 6P8D 50 1206	1
C 10	P210122	C# X7R MU 100N K 50 1206	1	C353	R111478	C EL RA 220M M 25E2 85	1
C 11	P210122	C# X7R MU 100N K 50 1206	1	C354	P210122	C# X7R MU 100N K 50 1206	1
C 12	P210122	C# X7R MU 100N K 50 1206	1	C355	P210064	C# COG MU 22P J 50 1206	1
C 13	P210122	C# X7R MU 100N K 50 1206	1	C356	P210122	C# X7R MU 100N K 50 1206	1
C 14	P210122	C# X7R MU 100N K 50 1206	1	C357	R111678	C EL BRA 10M M 25E2 85	1
C 15	R111477	C EL RA 100M Z 25E2 85	1	C358	P210122	C# X7R MU 100N K 50 1206	1
C 16	R111500	C EL RA 47M M 10E2 85	1	C359	P210122	C# X7R MU 100N K 50 1206	1
C 17	R111546	C EL RA 1M M 50E2 85	1	C360	P210092	C# X7R MU 10N K 50 1206	1
C132	P210092	C# X7R MU 10N K 50 1206	1	C361	P210148	C# Y5V MU 470N Z 50 1206	1
C150	R111468	C EL RA 470M Z 16E2 85	1	C366	P210029	C# COG MU 2N2J 50 1206	1
C151	P210122	C# X7R MU 100N K 50 1206	1	C367	R111510	C EL RA 22M M 25E2 85	1
C152	R111510	C EL RA 22M M 25E2 85	1	C370	P210076	C# COG MU 220P J 50 1206	1
C153	P210122	C# X7R MU 100N K 50 1206	1	C400	P210159	C# COG MU 18P J 50 1206	1
C154	P210122	C# X7R MU 100N K 50 1206	1	C401	P210122	C# X7R MU 100N K 50 1206	1
C155	P210122	C# X7R MU 100N K 50 1206	1	C402	R111678	C EL BRA 10M M 25E2 85	1
C156	P210122	C# X7R MU 100N K 50 1206	1	C403	P210122	C# X7R MU 100N K 50 1206	1
C157	P210122	C# X7R MU 100N K 50 1206	1	C420	P210122	C# X7R MU 100N K 50 1206	1
C201	P210122	C# X7R MU 100N K 50 1206	1	C421	P210122	C# X7R MU 100N K 50 1206	1
C202	R111678	C EL BRA 10M M 25E2 85	1	C422	P210122	C# X7R MU 100N K 50 1206	1
C203	P210122	C# X7R MU 100N K 50 1206	1	C423	P210122	C# X7R MU 100N K 50 1206	1
C220	R111678	C EL BRA 10M M 25E2 85	1	C424	P210073	C# COG MU 82P J 50 1206	1
C221	P210122	C# X7R MU 100N K 50 1206	1	C450	P210122	C# X7R MU 100N K 50 1206	1
C222	R114090	C POMERA 1M M 63E2	1	C451	P210074	C# COG MU 39P K 50 0805	1
C223	R114090	C POMERA 1M M 63E2	1	C452	P210236	C# COG MU 6P8D 50 1206	1
C224	R111510	C EL RA 22M M 25E2 85	1	C453	R111478	C EL RA 220M M 25E2 85	1
C225	P210122	C# X7R MU 100N K 50 1206	1	C454	P210122	C# X7R MU 100N K 50 1206	1
C226	R111678	C EL BRA 10M M 25E2 85	1	C455	P210064	C# COG MU 22P J 50 1206	1
C227	R111678	C EL BRA 10M M 25E2 85	1	C456	P210122	C# X7R MU 100N K 50 1206	1
C228	P210122	C# X7R MU 100N K 50 1206	1	C457	R111678	C EL BRA 10M M 25E2 85	1
C229	P210122	C# X7R MU 100N K 50 1206	1	C458	P210122	C# X7R MU 100N K 50 1206	1
C230	R111678	C EL BRA 10M M 25E2 85	1	C459	P210122	C# X7R MU 100N K 50 1206	1
C231	R112242	C NP0 MI 100P G100E2	1	C460	P210092	C# X7R MU 10N K 50 1206	1
C250	P210122	C# X7R MU 100N K 50 1206	1	C461	P210148	C# Y5V MU 470N Z 50 1206	1
C251	P210100	C# COG MU 47P J 50 1206	1	C462	R111510	C EL RA 22M M 25E2 85	1
C252	P210204	C# COG MU 8P2D 50 1206	1	C463	P210122	C# X7R MU 100N K 50 1206	1
C253	R111478	C EL RA 220M M 25E2 85	1	C464	P210122	C# X7R MU 100N K 50 1206	1
C254	P210122	C# X7R MU 100N K 50 1206	1	C465	P210122	C# X7R MU 100N K 50 1206	1
C255	P210064	C# COG MU 22P J 50 1206	1	C466	P210029	C# COG MU 2N2J 50 1206	1
				C467	R111510	C EL RA 22M M 25E2 85	1
				C470	P210076	C# COG MU 220P J 50 1206	1
				C500	R111678	C EL BRA 10M M 25E2 85	1
				C501	R111678	C EL BRA 10M M 25E2 85	1
				C502	P210122	C# X7R MU 100N K 50 1206	1
				C503	P210139	C# COG MU 33P J 50 1206	1

C504	P210092	C# X7R MU 10N K 50 1206	1	C625	R111510	C EL RA 22M M 25E2 85	1
C505	P210122	C# X7R MU 100N K 50 1206	1	C700	P210122	C# X7R MU 100N K 50 1206	1
C506	R111678	C EL BRA 10M M 25E2 85	1	C720	P210095	C# X7R MU 330N M 50 1812	1
C507	R111678	C EL BRA 10M M 25E2 85	1				
C508	P210092	C# X7R MU 10N K 50 1206	1	D 1	P234099	D#4148 R DMMELF	1
C509	P210122	C# X7R MU 100N K 50 1206	1	D 2	P234099	D#4148 R DMMELF	1
C510	P210139	C# COG MU 33P J 50 1206	1	D 3	P234099	D#4148 R DMMELF	1
C511	R111678	C EL BRA 10M M 25E2 85	1	D 4	P234099	D#4148 R DMMELF	1
C512	R111678	C EL BRA 10M M 25E2 85	1	D 5	P234055	D#BAT54 SCH SOT23	1
C515	P210122	C# X7R MU 100N K 50 1206	1	D 6	P234099	D#4148 R DMMELF	1
C517	P210122	C# X7R MU 100N K 50 1206	1	D 7	P234099	D#4148 R DMMELF	1
C518	R111678	C EL BRA 10M M 25E2 85	1	D 8	P234099	D#4148 R DMMELF	1
C519	R111678	C EL BRA 10M M 25E2 85	1	D 9	P234099	D#4148 R DMMELF	1
C520	P210092	C# X7R MU 10N K 50 1206	1	D 10	P234099	D#4148 R DMMELF	1
C521	P210122	C# X7R MU 100N K 50 1206	1	D 11	P234099	D#4148 R DMMELF	1
C522	P210122	C# X7R MU 100N K 50 1206	1	D 12	P234088	D#BZV87B2V0 STA DMMELF	1
C523	P210092	C# X7R MU 10N K 50 1206	1	D 13	P234099	D#4148 R DMMELF	1
C524	R111678	C EL BRA 10M M 25E2 85	1	D 14	P234088	D#BZV87B2V0 STA DMMELF	1
C525	R111678	C EL BRA 10M M 25E2 85	1	D 15	P234099	D#4148 R DMMELF	1
C526	P210122	C# X7R MU 100N K 50 1206	1	D 16	P234088	D#BZV87B2V0 STA DMMELF	1
C527	P210122	C# X7R MU 100N K 50 1206	1	D 17	R1316361	D Y BAT85 030200 DO34	1
C528	P210100	C# COG MU 47P J 50 1206	1	D 18	R1316361	D Y BAT85 030200 DO34	1
C529	P210122	C# X7R MU 100N K 50 1206	1	D200	P234099	D#4148 R DMMELF	1
C530	P210122	C# X7R MU 100N K 50 1206	1	D202	P234099	D#4148 R DMMELF	1
C531	P210092	C# X7R MU 10N K 50 1206	1	D203	P234099	D#4148 R DMMELF	1
C532	R111678	C EL BRA 10M M 25E2 85	1	D204	P234088	D#BZV87B2V0 STA DMMELF	1
C533	R111678	C EL BRA 10M M 25E2 85	1	D220	P234219	D#BZV87B1V4 STA DMMELF	1
C534	P210122	C# X7R MU 100N K 50 1206	1	D221	P234099	D#4148 R DMMELF	1
C535	P210122	C# X7R MU 100N K 50 1206	1	D250	P234099	D#4148 R DMMELF	1
C536	P210100	C# COG MU 47P J 50 1206	1	D251	P234099	D#4148 R DMMELF	1
C537	P210122	C# X7R MU 100N K 50 1206	1	D252	P234099	D#4148 R DMMELF	1
C538	R111678	C EL BRA 10M M 25E2 85	1	D253	P234088	D#BZV87B2V0 STA DMMELF	1
C539	R111678	C EL BRA 10M M 25E2 85	1	D254	R131667	D LED D3 T GN	1
C540	P210092	C# X7R MU 10N K 50 1206	1	D255	P234055	D#BAT54 SCH SOT23	1
C541	P210122	C# X7R MU 100N K 50 1206	1	D256	P234099	D#4148 R DMMELF	1
C542	P210122	C# X7R MU 100N K 50 1206	1	D257	P234055	D#BAT54 SCH SOT23	1
C543	P210122	C# X7R MU 100N K 50 1206	1	D258	P234099	D#4148 R DMMELF	1
C544	P210165	C# COG MU 39P J 50 1206	1	D260	R131826	D V BB112 008 SOD69	1
C545	P210122	C# X7R MU 100N K 50 1206	1	D261	P234259	D#BA682 S035A1 DMMELF	1
C546	R111510	C EL RA 22M M 25E2 85	1	D300	P234099	D#4148 R DMMELF	1
C547	P210122	C# X7R MU 100N K 50 1206	1	D302	P234099	D#4148 R DMMELF	1
C548	P210137	C# COG MU 100P J 50 1206	1	D303	P234099	D#4148 R DMMELF	1
C549	R111510	C EL RA 22M M 25E2 85	1	D350	P234099	D#4148 R DMMELF	1
C550	R111510	C EL RA 22M M 25E2 85	1	D351	P234099	D#4148 R DMMELF	1
C551	R111510	C EL RA 22M M 25E2 85	1	D352	P234099	D#4148 R DMMELF	1
C600	P210013	C# COG MU 1N J 50 1206	1	D353	P234088	D#BZV87B2V0 STA DMMELF	1
C603	P210095	C# X7R MU 330N M 50 1812	1	D354	R131667	D LED D3 T GN	1
C604	R111510	C EL RA 22M M 25E2 85	1	D355	P234055	D#BAT54 SCH SOT23	1
C605	P210122	C# X7R MU 100N K 50 1206	1	D356	P234099	D#4148 R DMMELF	1
C606	R111510	C EL RA 22M M 25E2 85	1	D357	P234055	D#BAT54 SCH SOT23	1
C607	P210095	C# X7R MU 330N M 50 1812	1	D358	P234099	D#4148 R DMMELF	1
C608	R111510	C EL RA 22M M 25E2 85	1	D360	R131826	D V BB112 008 SOD69	1
C609	P210122	C# X7R MU 100N K 50 1206	1	D361	P234259	D#BA682 S035A1 DMMELF	1
C610	R111164	C EL AX1000M T 25E14 85	1	D400	P234099	D#4148 R DMMELF	1
C611	P210095	C# X7R MU 330N M 50 1812	1	D402	P234099	D#4148 R DMMELF	1
C612	P210095	C# X7R MU 330N M 50 1812	1	D403	P234099	D#4148 R DMMELF	1
C613	R111510	C EL RA 22M M 25E2 85	1	D420	P234099	D#4148 R DMMELF	1
C614	P210095	C# X7R MU 330N M 50 1812	1	D421	P234099	D#4148 R DMMELF	1
C615	P210122	C# X7R MU 100N K 50 1206	1	D450	P234099	D#4148 R DMMELF	1
C616	R111468	C EL RA 470M Z 16E2 85	1	D451	P234099	D#4148 R DMMELF	1
C617	R111510	C EL RA 22M M 25E2 85	1	D452	P234099	D#4148 R DMMELF	1
C618	P210122	C# X7R MU 100N K 50 1206	1	D453	P234088	D#BZV87B2V0 STA DMMELF	1
C619	P210122	C# X7R MU 100N K 50 1206	1	D454	R131667	D LED D3 T GN	1
C620	R111571	C EL RA 2M2M350E2 85	1	D455	P234055	D#BAT54 SCH SOT23	1
C621	R111510	C EL RA 22M M 25E2 85	1	D456	P234099	D#4148 R DMMELF	1
C622	R111510	C EL RA 22M M 25E2 85	1	D457	P234055	D#BAT54 SCH SOT23	1
C623	R111510	C EL RA 22M M 25E2 85	1	D458	P234099	D#4148 R DMMELF	1
C624	P210122	C# X7R MU 100N K 50 1206	1	D459	R131635	D Y 5082-2800	1

D460	R131826	D V BB112	008	SOD69	1	D624	R131667	D LED D3	T GN	1
D461	P234259	D#BA682	S035A1	DMMELF	1	D625	P234099	D#4148	R DMMELF	1
D500	P234099	D#4148		R DMMELF	1	D626	P234055	D#BAT54	SCH SOT23	1
D501	P234099	D#4148		R DMMELF	1	D627	P234099	D#4148	R DMMELF	1
D502	P234099	D#4148		R DMMELF	1	D628	P234099	D#4148	R DMMELF	1
D503	P234099	D#4148		R DMMELF	1	D629	P234099	D#4148	R DMMELF	1
D504	P234099	D#4148		R DMMELF	1	D630	P234099	D#4148	R DMMELF	1
D505	P234099	D#4148		R DMMELF	1	D631	P234099	D#4148	R DMMELF	1
D506	P234099	D#4148		R DMMELF	1	D640	P234099	D#4148	R DMMELF	1
D507	P234099	D#4148		R DMMELF	1	D641	P234055	D#BAT54	SCH SOT23	1
D508	P234099	D#4148		R DMMELF	1	D642	P234099	D#4148	R DMMELF	1
D509	P234099	D#4148		R DMMELF	1	D643	P234055	D#BAT54	SCH SOT23	1
D510	P234099	D#4148		R DMMELF	1	D644	P234099	D#4148	R DMMELF	1
D511	P234099	D#4148		R DMMELF	1	D645	P234055	D#BAT54	SCH SOT23	1
D512	P234099	D#4148		R DMMELF	1	D646	P234099	D#4148	R DMMELF	1
D513	P234099	D#4148		R DMMELF	1	D647	P234099	D#4148	R DMMELF	1
D514	P234099	D#4148		R DMMELF	1	D699	R1319481	D R BYD33J	6001A3 SOD81	1
D515	P234099	D#4148		R DMMELF	1	D700	P234099	D#4148	R DMMELF	1
D516	P234099	D#4148		R DMMELF	1	D701	P234099	D#4148	R DMMELF	1
D517	P234099	D#4148		R DMMELF	1	D702	P234099	D#4148	R DMMELF	1
D518	P234099	D#4148		R DMMELF	1	D703	P234099	D#4148	R DMMELF	1
D519	P234099	D#4148		R DMMELF	1	D704	P234196	D#BYD37J	AVA SOD87	1
D520	P234099	D#4148		R DMMELF	1	D770	P234099	D#4148	R DMMELF	1
D521	P234099	D#4148		R DMMELF	1	D771	P234099	D#4148	R DMMELF	1
D522	P234099	D#4148		R DMMELF	1	D772	P234099	D#4148	R DMMELF	1
D523	P234099	D#4148		R DMMELF	1	D774	P234099	D#4148	R DMMELF	1
D524	P234099	D#4148		R DMMELF	1	D775	P234099	D#4148	R DMMELF	1
D525	P234099	D#4148		R DMMELF	1	D777	P234099	D#4148	R DMMELF	1
D526	P234099	D#4148		R DMMELF	1	D780	P234099	D#4148	R DMMELF	1
D527	P234099	D#4148		R DMMELF	1	D781	P234099	D#4148	R DMMELF	1
D528	P234099	D#4148		R DMMELF	1	D782	P234099	D#4148	R DMMELF	1
D529	P234099	D#4148		R DMMELF	1	D783	P234099	D#4148	R DMMELF	1
D530	P234099	D#4148		R DMMELF	1	I 1	R137011	U 74HCT153	DIP16 P	1
D531	P234099	D#4148		R DMMELF	1	I 2	R137598	U 74HC04	DIP14 P	1
D532	P234099	D#4148		R DMMELF	1	I 3	R137598	U 74HC04	DIP14 P	1
D533	P234099	D#4148		R DMMELF	1	I 4	R134125	U 34084	DIP14 P	1
D534	P234099	D#4148		R DMMELF	1	I 5	R134113	U 084 TL	DIP14 P	1
D535	P234099	D#4148		R DMMELF	1	I 6	R132833	U 76013 SC	DIP28 P	1
D536	P234099	D#4148		R DMMELF	1	I 7	R132833	U 76013 SC	DIP28 P	1
D537	P234099	D#4148		R DMMELF	1	I 8	R132833	U 76013 SC	DIP28 P	1
D538	P234099	D#4148		R DMMELF	1	I 9	R136600	U 74HC4066	DIP14 P	1
D539	P234099	D#4148		R DMMELF	1	I131	R1328261	U 1203B LM	DIP28 P	1
D540	P234099	D#4148		R DMMELF	1	I200	R137583	U 74HC4053	DIP16 P	1
D541	P234099	D#4148		R DMMELF	1	I201	R137583	U 74HC4053	DIP16 P	1
D542	P234099	D#4148		R DMMELF	1	I202	R136600	U 74HC4066	DIP14 P	1
D600	P234099	D#4148		R DMMELF	1	I203	R136600	U 74HC4066	DIP14 P	1
D601	P234099	D#4148		R DMMELF	1	I220	R134124	U 082 TL	DIP8 P	1
D602	P234196	D#BYD37J	AVA	SOD87	1	I221	R132134	U 331 TBA	DIP14 P	1
D603	P234196	D#BYD37J	AVA	SOD87	1	I250	R134225	U 2082 EL	DIP8 P	1
D604	P234099	D#4148		R DMMELF	1	I251	R134145	U 3080 CA	DIP8 P	1
D605	P234099	D#4148		R DMMELF	1	I252	R134114	U 393 LM	DIP8 P	1
D606	P234055	D#BAT54	SCH	SOT23	1	I253	R137583	U 74HC4053	DIP16 P	1
D607	P234055	D#BAT54	SCH	SOT23	1	I254	R134113	U 084 TL	DIP14 P	1
D608	P234055	D#BAT54	SCH	SOT23	1	I350	R134225	U 2082 EL	DIP8 P	1
D609	P234196	D#BYD37J	AVA	SOD87	1	I351	R134145	U 3080 CA	DIP8 P	1
D610	P234196	D#BYD37J	AVA	SOD87	1	I352	R134114	U 393 LM	DIP8 P	1
D611	R131667	D LED D3	T GN		1	I353	R137583	U 74HC4053	DIP16 P	1
D612	R131667	D LED D3	T GN		1	I354	R134113	U 084 TL	DIP14 P	1
D613	R131667	D LED D3	T GN		1	I450	R134225	U 2082 EL	DIP8 P	1
D614	R131667	D LED D3	T GN		1	I451	R134145	U 3080 CA	DIP8 P	1
D615	P234099	D#4148		R DMMELF	1	I452	R134114	U 393 LM	DIP8 P	1
D616	P234055	D#BAT54	SCH	SOT23	1	I453	R137583	U 74HC4053	DIP16 P	1
D617	P234099	D#4148		R DMMELF	1	I454	R134113	U 084 TL	DIP14 P	1
D618	P234099	D#4148		R DMMELF	1	I455	R134145	U 3080 CA	DIP8 P	1
D619	P234055	D#BAT54	SCH	SOT23	1	I600	R137546	U 74HCT32	DIP14 P	1
D620	P234055	D#BAT54	SCH	SOT23	1	I601	R137598	U 74HC04	DIP14 P	1
D621	P234099	D#4148		R DMMELF	1	I602	R134001	U 7805	TO220 P	1
D623	R131667	D LED D3	T GN		1					

I603	R134016	U 7912	TO220 P	1	Q222	P232044	Q#BC859B	P SS SOT23	1
I604	R134032	U 78L05	TO92 P	1	Q223	P232044	Q#BC859B	P SS SOT23	1
I605	R134002	U 7812	TO220 P	1	Q224	P232043	Q#BC849B	N SS SOT23	1
I606	R137492	U 74LS42	DIP16 P	1	Q250	P232046	Q#BSS123	F SS SOT23	1
I607	R132832	U 8574A	PCF DIP16 P	1	Q251	P232046	Q#BSS123	F SS SOT23	1
J 3	R313932	J C T H	MBT P12 M2SN	1	Q252	P232076	Q#BFS17	N SS SOT23	1
J206	R3135005	J D E P8	MBS P 9 FUMBLPGDB	1	Q253	R132911	Q 2N5583	P SS TO39	1
J210	R313935	J C T H	MBT P15 M2SN	1	Q254	P232043	Q#BC849B	N SS SOT23	1
J213	R3130421	J P H N	FCS D 2.5MON P	1	Q255	P232044	Q#BC859B	P SS SOT23	1
J217	R313896	J B N C	FBS P 5 50E SIP	1	Q256	P232044	Q#BC859B	P SS SOT23	1
J235	R313851	J C I R C	FBS P 4 M	1	Q300	P232044	Q#BC859B	P SS SOT23	1
J400	R313932	J C T H	MBT P12 M2SN	1	Q301	P232044	Q#BC859B	P SS SOT23	1
J401	R313928	J C T H	MBT P 8 M2SN	1	Q302	P232076	Q#BFS17	N SS SOT23	1
J402	R313928	J C T H	MBT P 8 M2SN	1	Q350	P232046	Q#BSS123	F SS SOT23	1
J405	R313927	J C T H	MBT P 7 M2SN	1	Q351	P232046	Q#BSS123	F SS SOT23	1
J452	R3132862	J M D 1	MBT P 2 E1SN	1	Q352	P232076	Q#BFS17	N SS SOT23	1
J500	R3132862	J M D 1	MBT P 2 E1SN	1	Q353	R132911	Q 2N5583	P SS TO39	1
J501	R3132862	J M D 1	MBT P 2 E1SN	1	Q354	P232043	Q#BC849B	N SS SOT23	1
J503	R3132862	J M D 1	MBT P 2 E1SN	1	Q355	P232044	Q#BC859B	P SS SOT23	1
J504	R3132862	J M D 1	MBT P 2 E1SN	1	Q356	P232044	Q#BC859B	P SS SOT23	1
J505	R3132862	J M D 1	MBT P 2 E1SN	1	Q400	P232044	Q#BC859B	P SS SOT23	1
J506	R3132862	J M D 1	MBT P 2 E1SN	1	Q401	P232044	Q#BC859B	P SS SOT23	1
J550	R313935	J C T H	MBT P15 M2SN	1	Q402	P232076	Q#BFS17	N SS SOT23	1
J560	R313935	J C T H	MBT P15 M2SN	1	Q420	P232043	Q#BC849B	N SS SOT23	1
J570	R313935	J C T H	MBT P15 M2SN	1	Q421	R132904	Q 2N2905A	P SS TO39	1
J580	R313925	J C T H	MBT P 5 M2SN	1	Q450	P232046	Q#BSS123	F SS SOT23	1
J701	R313930	J C T H	MBT P10 M2SN	1	Q451	P232046	Q#BSS123	F SS SOT23	1
J703	R313924	J C T H	MBT P 4 M2SN	1	Q452	P232076	Q#BFS17	N SS SOT23	1
J741	R313928	J C T H	MBT P 8 M2SN	1	Q453	R132911	Q 2N5583	P SS TO39	1
J757	R313932	J C T H	MBT P12 M2SN	1	Q454	P232043	Q#BC849B	N SS SOT23	1
J778	R313929	J C T H	MBT P 9 M2SN	1	Q455	P232044	Q#BC859B	P SS SOT23	1
J779	R313931	J C T H	MBT P11 M2SN	1	Q456	P232044	Q#BC859B	P SS SOT23	1
L150	R3061322	CH A X	NS 10 UH	1	Q457	P232101	Q#BC859C	P SS SOT23	1
L241	R3061322	CH A X	NS 10 UH	1	Q500	P232043	Q#BC849B	N SS SOT23	1
L242	R3061322	CH A X	NS 10 UH	1	Q501	P232043	Q#BC849B	N SS SOT23	1
L243	R3061322	CH A X	NS 10 UH	1	Q502	P232043	Q#BC849B	N SS SOT23	1
L601	R3061322	CH A X	NS 10 UH	1	Q503	P232043	Q#BC849B	N SS SOT23	1
L602	R3061322	CH A X	NS 10 UH	1	Q504	P232043	Q#BC849B	N SS SOT23	1
L603	R3061322	CH A X	NS 10 UH	1	Q505	P232043	Q#BC849B	N SS SOT23	1
L720	R3061582	CH A X	NS 1.5 MH	1	Q506	P232043	Q#BC849B	N SS SOT23	1
P250	R107004	R T C E	H200E K 0W5 S 7TS	1	Q507	P232043	Q#BC849B	N SS SOT23	1
P251	R107005	R T C E	H500E K 0W5 S 7TS	1	Q508	P232043	Q#BC849B	N SS SOT23	1
P350	R107004	R T C E	H200E K 0W5 S 7TS	1	Q509	P232043	Q#BC849B	N SS SOT23	1
P351	R107005	R T C E	H500E K 0W5 S 7TS	1	Q510	P232043	Q#BC849B	N SS SOT23	1
P450	R107004	R T C E	H200E K 0W5 S 7TS	1	Q511	P232043	Q#BC849B	N SS SOT23	1
P451	R107005	R T C E	H500E K 0W5 S 7TS	1	Q512	P232043	Q#BC849B	N SS SOT23	1
PC	R780352	PCD#PJ53 D 700	RGB DRV	1	Q513	P232076	Q#BFS17	N SS SOT23	1
Q 1	P232044	Q#BC859B	P SS SOT23	1	Q514	P232076	Q#BFS17	N SS SOT23	1
Q 2	P232044	Q#BC859B	P SS SOT23	1	Q515	P232043	Q#BC849B	N SS SOT23	1
Q 3	P232043	Q#BC849B	N SS SOT23	1	Q516	P232076	Q#BFS17	N SS SOT23	1
Q 4	P232044	Q#BC859B	P SS SOT23	1	Q517	P232076	Q#BFS17	N SS SOT23	1
Q 5	P232043	Q#BC849B	N SS SOT23	1	Q518	P232043	Q#BC849B	N SS SOT23	1
Q 6	P232044	Q#BC859B	P SS SOT23	1	Q519	P232076	Q#BFS17	N SS SOT23	1
Q 7	P232043	Q#BC849B	N SS SOT23	1	Q520	P232076	Q#BFS17	N SS SOT23	1
Q 8	P232043	Q#BC849B	N SS SOT23	1	Q521	P232076	Q#BFS17	N SS SOT23	1
Q 9	P232043	Q#BC849B	N SS SOT23	1	Q522	P232043	Q#BC849B	N SS SOT23	1
Q 10	P232044	Q#BC859B	P SS SOT23	1	Q523	P232044	Q#BC859B	P SS SOT23	1
Q 23	P232043	Q#BC849B	N SS SOT23	1	Q524	P232044	Q#BC859B	P SS SOT23	1
Q200	P232044	Q#BC859B	P SS SOT23	1	Q525	P232044	Q#BC859B	P SS SOT23	1
Q201	P232044	Q#BC859B	P SS SOT23	1	Q526	P232044	Q#BC859B	P SS SOT23	1
Q202	P232076	Q#BFS17	N SS SOT23	1	Q527	P232044	Q#BC859B	P SS SOT23	1
Q220	P232044	Q#BC859B	P SS SOT23	1	Q620	P232043	Q#BC849B	N SS SOT23	1
Q221	P232044	Q#BC859B	P SS SOT23	1	Q621	R131471	Q BF458	N P TO126	1
					Q622	P232042	Q#BC807-25	P SS SOT23	1
					Q623	P232043	Q#BC849B	N SS SOT23	1
					Q624	P232042	Q#BC807-25	P SS SOT23	1
					Q625	P232044	Q#BC859B	P SS SOT23	1
					Q626	P232043	Q#BC849B	N SS SOT23	1




Q627	P232042	Q#BC807-25	P SS SOT23	1	R 57	P200109	R# CE H 33K J 0W12 1206	1
Q628	P232043	Q#BC849B	N SS SOT23	1	R 58	P200097	R# CE H 10K J 0W12 1206	1
Q629	P232042	Q#BC807-25	P SS SOT23	1	R 59	P200091	R# CE H 5K6 J 0W12 1206	1
Q630	P232043	Q#BC849B	N SS SOT23	1	R 60	P200097	R# CE H 10K J 0W12 1206	1
Q631	P232043	Q#BC849B	N SS SOT23	1	R 61	P200097	R# CE H 10K J 0W12 1206	1
Q632	P232043	Q#BC849B	N SS SOT23	1	R 62	P200097	R# CE H 10K J 0W12 1206	1
Q633	P232043	Q#BC849B	N SS SOT23	1	R 63	P200091	R# CE H 5K6 J 0W12 1206	1
Q634	P232043	Q#BC849B	N SS SOT23	1	R 64	P200109	R# CE H 33K J 0W12 1206	1
Q720	P232044	Q#BC859B	P SS SOT23	1	R 65	P200395	R# CE H220E F 0W12 1206	1
Q721	P232043	Q#BC849B	N SS SOT23	1	R 66	P200404	R# CE H510E F 0W12 1206	1
Q722	P232043	Q#BC849B	N SS SOT23	1	R 67	P200402	R# CE H430E F 0W12 1206	1
R	R1015376	R MF H243E F 0W4 E3		1	R 68	P200115	R# CE H 56K J 0W12 1206	1
R 1	P200073	R# CE H 1K J 0W12 1206		1	R 69	P200113	R# CE H 47K J 0W12 1206	1
R 2	P200049	R# CE H100E J 0W12 1206		1	R 70	P200097	R# CE H 10K J 0W12 1206	1
R 3	P200097	R# CE H 10K J 0W12 1206		1	R 71	P200075	R# CE H 1K2 J 0W12 1206	1
R 4	P200097	R# CE H 10K J 0W12 1206		1	R 72	P200097	R# CE H 10K J 0W12 1206	1
R 5	P200089	R# CE H 4K7 J 0W12 1206		1	R 73	P200113	R# CE H 47K J 0W12 1206	1
R 6	P200089	R# CE H 4K7 J 0W12 1206		1	R 74	P200107	R# CE H 27K J 0W12 1206	1
R 8	P200109	R# CE H 33K J 0W12 1206		1	R 75	P200121	R# CE H100K J 0W12 1206	1
R 9	P200089	R# CE H 4K7 J 0W12 1206		1	R 76	P200075	R# CE H 1K2 J 0W12 1206	1
R 10	P200113	R# CE H 47K J 0W12 1206		1	R 77	P200109	R# CE H 33K J 0W12 1206	1
R 11	P200097	R# CE H 10K J 0W12 1206		1	R 78	P200083	R# CE H 2K7 J 0W12 1206	1
R 12	P200091	R# CE H 5K6 J 0W12 1206		1	R 79	P200049	R# CE H100E J 0W12 1206	1
R 13	P200065	R# CE H470E J 0W12 1206		1	R 80	P200095	R# CE H 8K2 J 0W12 1206	1
R 14	P200065	R# CE H470E J 0W12 1206		1	R 81	P200049	R# CE H100E J 0W12 1206	1
R 15	P200081	R# CE H 2K2 J 0W12 1206		1	R 82	P200396	R# CE H240E F 0W12 1206	1
R 16	P200081	R# CE H 2K2 J 0W12 1206		1	R 84	P200453	R# CE H 56K F 0W12 1206	1
R 17	P200081	R# CE H 2K2 J 0W12 1206		1	R 85	P200416	R# CE H 1K6 F 0W12 1206	1
R 18	P200089	R# CE H 4K7 J 0W12 1206		1	R 86	P200427	R# CE H 4K7 F 0W12 1206	1
R 19	P200041	R# CE H 47E J 0W12 1206		1	R 87	P200459	R# CE H100K F 0W12 1206	1
R 20	P200065	R# CE H470E J 0W12 1206		1	R 88	P200459	R# CE H100K F 0W12 1206	1
R 21	P200065	R# CE H470E J 0W12 1206		1	R 89	P200456	R# CE H 75K F 0W12 1206	1
R 22	P200451	R# CE H 47K F 0W12 1206		1	R 90	P200421	R# CE H 2K7 F 0W12 1206	1
R 23	P200065	R# CE H470E J 0W12 1206		1	R 91	P200432	R# CE H 7K5 F 0W12 1206	1
R 24	P200065	R# CE H470E J 0W12 1206		1	R 92	P200431	R# CE H 6K8 F 0W12 1206	1
R 25	P200049	R# CE H100E J 0W12 1206		1	R150	P200041	R# CE H 47E J 0W12 1206	1
R 26	P200451	R# CE H 47K F 0W12 1206		1	R151	P200097	R# CE H 10K J 0W12 1206	1
R 27	P200423	R# CE H 3K3 F 0W12 1206		1	R152	P200049	R# CE H100E J 0W12 1206	1
R 28	P200423	R# CE H 3K3 F 0W12 1206		1	R153	P200049	R# CE H100E J 0W12 1206	1
R 29	P200423	R# CE H 3K3 F 0W12 1206		1	R200	P200049	R# CE H100E J 0W12 1206	1
R 30	P200423	R# CE H 3K3 F 0W12 1206		1	R201	P200383	R# CE H 68E F 0W12 1206	1
R 31	R101548	R MF H 10K F 0W4 E3		1	R202	P200384	R# CE H 75E F 0W12 1206	1
R 32	P200423	R# CE H 3K3 F 0W12 1206		1	R203	P200397	R# CE H270E F 0W12 1206	1
R 33	P200423	R# CE H 3K3 F 0W12 1206		1	R204	P200384	R# CE H 75E F 0W12 1206	1
R 34	P200432	R# CE H 7K5 F 0W12 1206		1	R206	P200385	R# CE H 82E F 0W12 1206	1
R 35	P200423	R# CE H 3K3 F 0W12 1206		1	R207	P200079	R# CE H 1K8 J 0W12 1206	1
R 36	P200443	R# CE H 22K F 0W12 1206		1	R208	P200057	R# CE H220E J 0W12 1206	1
R 37	P200463	R# CE H150K F 0W12 1206		1	R209	P200384	R# CE H 75E F 0W12 1206	1
R 38	P200379	R# CE H 47E F 0W12 1206		1	R220	P200091	R# CE H 5K6 J 0W12 1206	1
R 39	P200379	R# CE H 47E F 0W12 1206		1	R221	P200397	R# CE H270E F 0W12 1206	1
R 40	P200379	R# CE H 47E F 0W12 1206		1	R222	P200397	R# CE H270E F 0W12 1206	1
R 41	P200379	R# CE H 47E F 0W12 1206		1	R223	P200397	R# CE H270E F 0W12 1206	1
R 42	P200379	R# CE H 47E F 0W12 1206		1	R224	P200405	R# CE H560E F 0W12 1206	1
R 43	P200379	R# CE H 47E F 0W12 1206		1	R225	P200405	R# CE H560E F 0W12 1206	1
R 44	P200097	R# CE H 10K J 0W12 1206		1	R226	P200414	R# CE H 1K3 F 0W12 1206	1
R 45	P200091	R# CE H 5K6 J 0W12 1206		1	R227	P200399	R# CE H330E F 0W12 1206	1
R 46	P200097	R# CE H 10K J 0W12 1206		1	R228	P200119	R# CE H 82K J 0W12 1206	1
R 47	P200097	R# CE H 10K J 0W12 1206		1	R229	P200119	R# CE H 82K J 0W12 1206	1
R 48	P200097	R# CE H 10K J 0W12 1206		1	R230	P200123	R# CE H120K J 0W12 1206	1
R 49	P200091	R# CE H 5K6 J 0W12 1206		1	R231	P200123	R# CE H120K J 0W12 1206	1
R 50	P200109	R# CE H 33K J 0W12 1206		1	R232	P200113	R# CE H 47K J 0W12 1206	1
R 51	P200097	R# CE H 10K J 0W12 1206		1	R233	P200113	R# CE H 47K J 0W12 1206	1
R 52	P200091	R# CE H 5K6 J 0W12 1206		1	R234	P200097	R# CE H 10K J 0W12 1206	1
R 53	P200097	R# CE H 10K J 0W12 1206		1	R235	P200097	R# CE H 10K J 0W12 1206	1
R 54	P200097	R# CE H 10K J 0W12 1206		1	R236	P200397	R# CE H270E F 0W12 1206	1
R 55	P200097	R# CE H 10K J 0W12 1206		1	R237	P200405	R# CE H560E F 0W12 1206	1
R 56	P200091	R# CE H 5K6 J 0W12 1206		1	R238	P200405	R# CE H560E F 0W12 1206	1
					R239	P200420	R# CE H 2K4 F 0W12 1206	1



R240	P200397	R# CE H270E F 0W12 1206	1	R354	P200079	R# CE H 1K8 J 0W12 1206	1
R241	R101520	R MF H 47E F 0W4 E3	1	R355	P200418	R# CE H 2K F 0W12 1206	1
R242	P200097	R# CE H 10K J 0W12 1206	1	R356	P200387	R# CE H100E F 0W12 1206	1
R243	P200111	R# CE H 39K J 0W12 1206	1	R357	P200081	R# CE H 2K2 J 0W12 1206	1
R244	P200025	R# CE H 10E J 0W12 1206	1	R358	P200398	R# CE H300E F 0W12 1206	1
R245	P200033	R# CE H 22E J 0W12 1206	1	R359	P200404	R# CE H510E F 0W12 1206	1
R250	P200127	R# CE H180K J 0W12 1206	1	R360	P200091	R# CE H 5K6 J 0W12 1206	1
R251	P200041	R# CE H 47E J 0W12 1206	1	R361	P200399	R# CE H330E F 0W12 1206	1
R252	P200073	R# CE H 1K J 0W12 1206	1	R362	P200113	R# CE H 47K J 0W12 1206	1
R253	P200399	R# CE H330E F 0W12 1206	1	R363	P200049	R# CE H100E J 0W12 1206	1
R254	P200081	R# CE H 2K2 J 0W12 1206	1	R364	P200057	R# CE H220E J 0W12 1206	1
R255	P200418	R# CE H 2K F 0W12 1206	1	R365	P200065	R# CE H470E J 0W12 1206	1
R256	P200387	R# CE H100E F 0W12 1206	1	R366	P200047	R# CE H 82E J 0W12 1206	1
R257	P200081	R# CE H 2K2 J 0W12 1206	1	R367	P200404	R# CE H510E F 0W12 1206	1
R258	P200398	R# CE H300E F 0W12 1206	1	R368	P200017	R# CE H 4E7 J 0W12 1206	1
R259	P200404	R# CE H510E F 0W12 1206	1	R369	P200083	R# CE H 2K7 J 0W12 1206	1
R260	P200091	R# CE H 5K6 J 0W12 1206	1	R370	P200065	R# CE H470E J 0W12 1206	1
R261	P200399	R# CE H330E F 0W12 1206	1	R371	P200079	R# CE H 1K8 J 0W12 1206	1
R262	P200113	R# CE H 47K J 0W12 1206	1	R372	P200447	R# CE H 33K F 0W12 1206	1
R263	P200049	R# CE H100E J 0W12 1206	1	R373	P200091	R# CE H 5K6 J 0W12 1206	1
R264	P200057	R# CE H220E J 0W12 1206	1	R374	P200416	R# CE H 1K6 F 0W12 1206	1
R265	P200065	R# CE H470E J 0W12 1206	1	R375	P200055	R# CE H180E J 0W12 1206	1
R266	P200047	R# CE H 82E J 0W12 1206	1	R376	P200435	R# CE H 10K F 0W12 1206	1
R267	P200404	R# CE H510E F 0W12 1206	1	R377	P200081	R# CE H 2K2 J 0W12 1206	1
R268	P200017	R# CE H 4E7 J 0W12 1206	1	R378	P200081	R# CE H 2K2 J 0W12 1206	1
R269	P200083	R# CE H 2K7 J 0W12 1206	1	R379	P200109	R# CE H 33K J 0W12 1206	1
R270	P200065	R# CE H470E J 0W12 1206	1	R380	P200085	R# CE H 3K3 J 0W12 1206	1
R271	P200079	R# CE H 1K8 J 0W12 1206	1	R381	P200121	R# CE H100K J 0W12 1206	1
R272	P200447	R# CE H 33K F 0W12 1206	1	R382	P200119	R# CE H 82K J 0W12 1206	1
R273	P200091	R# CE H 5K6 J 0W12 1206	1	R383	P200109	R# CE H 33K J 0W12 1206	1
R274	P200416	R# CE H 1K6 F 0W12 1206	1	R384	P200097	R# CE H 10K J 0W12 1206	1
R275	P200055	R# CE H180E J 0W12 1206	1	R385	P200097	R# CE H 10K J 0W12 1206	1
R276	P200435	R# CE H 10K F 0W12 1206	1	R386	P200049	R# CE H100E J 0W12 1206	1
R277	P200081	R# CE H 2K2 J 0W12 1206	1	R394	P200097	R# CE H 10K J 0W12 1206	1
R278	P200081	R# CE H 2K2 J 0W12 1206	1	R395	P200121	R# CE H100K J 0W12 1206	1
R279	P200109	R# CE H 33K J 0W12 1206	1	R396	P200083	R# CE H 2K7 J 0W12 1206	1
R280	P200085	R# CE H 3K3 J 0W12 1206	1	R397	P200025	R# CE H 10E J 0W12 1206	1
R281	P200121	R# CE H100K J 0W12 1206	1	R400	P200049	R# CE H100E J 0W12 1206	1
R282	P200119	R# CE H 82K J 0W12 1206	1	R401	P200383	R# CE H 68E F 0W12 1206	1
R283	P200109	R# CE H 33K J 0W12 1206	1	R402	P200384	R# CE H 75E F 0W12 1206	1
R284	P200097	R# CE H 10K J 0W12 1206	1	R403	P200397	R# CE H270E F 0W12 1206	1
R285	P200097	R# CE H 10K J 0W12 1206	1	R404	P200384	R# CE H 75E F 0W12 1206	1
R286	P200049	R# CE H100E J 0W12 1206	1	R405	P200059	R# CE H270E J 0W12 1206	1
R294	P200097	R# CE H 10K J 0W12 1206	1	R406	P200385	R# CE H 82E F 0W12 1206	1
R295	P200121	R# CE H100K J 0W12 1206	1	R407	P200079	R# CE H 1K8 J 0W12 1206	1
R296	P200083	R# CE H 2K7 J 0W12 1206	1	R408	P200057	R# CE H220E J 0W12 1206	1
R297	P200025	R# CE H 10E J 0W12 1206	1	R409	P200384	R# CE H 75E F 0W12 1206	1
R300	P200049	R# CE H100E J 0W12 1206	1	R420	P200065	R# CE H470E J 0W12 1206	1
R301	P200383	R# CE H 68E F 0W12 1206	1	R421	P200095	R# CE H 8K2 J 0W12 1206	1
R302	P200384	R# CE H 75E F 0W12 1206	1	R422	P200049	R# CE H100E J 0W12 1206	1
R303	P200397	R# CE H270E F 0W12 1206	1	R423	P200089	R# CE H 4K7 J 0W12 1206	1
R304	P200384	R# CE H 75E F 0W12 1206	1	R424	P200067	R# CE H560E J 0W12 1206	1
R305	P200035	R# CE H 27E J 0W12 1206	1	R425	P200017	R# CE H 4E7 J 0W12 1206	1
R306	P200385	R# CE H 82E F 0W12 1206	1	R426	P200121	R# CE H100K J 0W12 1206	1
R307	P200079	R# CE H 1K8 J 0W12 1206	1	R427	P200025	R# CE H 10E J 0W12 1206	1
R308	P200057	R# CE H220E J 0W12 1206	1	R428	P200053	R# CE H150E J 0W12 1206	1
R309	P200046	R# CE H 75E J 0W12 1206	1	R429	P200083	R# CE H 2K7 J 0W12 1206	1
R320	P200121	R# CE H100K J 0W12 1206	1	R450	P200127	R# CE H180K J 0W12 1206	1
R321	P200104	R# CE H 20K J 0W12 1206	1	R451	P200041	R# CE H 47E J 0W12 1206	1
R322	P200041	R# CE H 47E J 0W12 1206	1	R452	P200073	R# CE H 1K J 0W12 1206	1
R323	P200065	R# CE H470E J 0W12 1206	1	R453	P200399	R# CE H330E F 0W12 1206	1
R324	P200097	R# CE H 10K J 0W12 1206	1	R454	P200079	R# CE H 1K8 J 0W12 1206	1
R325	P200097	R# CE H 10K J 0W12 1206	1	R455	P200418	R# CE H 2K F 0W12 1206	1
R326	P200025	R# CE H 10E J 0W12 1206	1	R456	P200387	R# CE H100E F 0W12 1206	1
R350	P200127	R# CE H180K J 0W12 1206	1	R457	P200081	R# CE H 2K2 J 0W12 1206	1
R351	P200041	R# CE H 47E J 0W12 1206	1	R458	P200398	R# CE H300E F 0W12 1206	1
R352	P200073	R# CE H 1K J 0W12 1206	1	R459	P200404	R# CE H510E F 0W12 1206	1
R353	P200399	R# CE H330E F 0W12 1206	1	R460	P200091	R# CE H 5K6 J 0W12 1206	1



R461	P200399	R# CE H330E F 0W12 1206	1	R532	P200399	R# CE H330E F 0W12 1206	1
R462	P200113	R# CE H 47K J 0W12 1206	1	R534	P200049	R# CE H100E J 0W12 1206	1
R463	P200049	R# CE H100E J 0W12 1206	1	R535	P200111	R# CE H 39K J 0W12 1206	1
R464	P200057	R# CE H220E J 0W12 1206	1	R536	P200111	R# CE H 39K J 0W12 1206	1
R465	P200065	R# CE H470E J 0W12 1206	1	R537	P200049	R# CE H100E J 0W12 1206	1
R466	P200047	R# CE H 82E J 0W12 1206	1	R538	P200384	R# CE H 75E F 0W12 1206	1
R467	P200404	R# CE H510E F 0W12 1206	1	R539	P200059	R# CE H270E J 0W12 1206	1
R468	P200017	R# CE H 4E7 J 0W12 1206	1	R540	P200083	R# CE H 2K7 J 0W12 1206	1
R469	P200083	R# CE H 2K7 J 0W12 1206	1	R541	P200107	R# CE H 27K J 0W12 1206	1
R470	P200065	R# CE H470E J 0W12 1206	1	R542	P200397	R# CE H270E F 0W12 1206	1
R471	P200079	R# CE H 1K8 J 0W12 1206	1	R543	P200397	R# CE H270E F 0W12 1206	1
R472	P200447	R# CE H 33K F 0W12 1206	1	R544	P200083	R# CE H 2K7 J 0W12 1206	1
R473	P200091	R# CE H 5K6 J 0W12 1206	1	R545	P200384	R# CE H 75E F 0W12 1206	1
R474	P200416	R# CE H 1K6 F 0W12 1206	1	R546	P200049	R# CE H100E J 0W12 1206	1
R475	P200055	R# CE H180E J 0W12 1206	1	R547	P200085	R# CE H 3K3 J 0W12 1206	1
R476	P200435	R# CE H 10K F 0W12 1206	1	R548	P200085	R# CE H 3K3 J 0W12 1206	1
R477	P200081	R# CE H 2K2 J 0W12 1206	1	R549	P200049	R# CE H100E J 0W12 1206	1
R478	P200081	R# CE H 2K2 J 0W12 1206	1	R550	P200025	R# CE H 10E J 0W12 1206	1
R479	P200109	R# CE H 1K5 J 0W12 1206	1	R551	P200051	R# CE H120E J 0W12 1206	1
R480	P200085	R# CE H 3K3 J 0W12 1206	1	R552	P200049	R# CE H100E J 0W12 1206	1
R481	P200121	R# CE H100K J 0W12 1206	1	R553	P200389	R# CE H120E F 0W12 1206	1
R482	P200119	R# CE H 82K J 0W12 1206	1	R554	P200389	R# CE H120E F 0W12 1206	1
R483	P200109	R# CE H 33K J 0W12 1206	1	R555	P200033	R# CE H 22E J 0W12 1206	1
R484	P200097	R# CE H 10K J 0W12 1206	1	R556	P200059	R# CE H270E J 0W12 1206	1
R485	P200097	R# CE H 10K J 0W12 1206	1	R557	P200083	R# CE H 2K7 J 0W12 1206	1
R486	P200049	R# CE H100E J 0W12 1206	1	R558	P200384	R# CE H 75E F 0W12 1206	1
R487	P200385	R# CE H 82E F 0W12 1206	1	R559	P200049	R# CE H100E J 0W12 1206	1
R488	P200077	R# CE H 1K5 J 0W12 1206	1	R560	P200085	R# CE H 3K3 J 0W12 1206	1
R489	P200075	R# CE H 1K2 J 0W12 1206	1	R561	P200085	R# CE H 3K3 J 0W12 1206	1
R490	P200075	R# CE H 1K2 J 0W12 1206	1	R562	P200049	R# CE H100E J 0W12 1206	1
R492	P200459	R# CE H100K F 0W12 1206	1	R563	P200025	R# CE H 10E J 0W12 1206	1
R493	P200077	R# CE H 1K5 J 0W12 1206	1	R564	P200051	R# CE H120E J 0W12 1206	1
R494	P200097	R# CE H 10K J 0W12 1206	1	R565	P200049	R# CE H100E J 0W12 1206	1
R495	P200121	R# CE H100K J 0W12 1206	1	R566	P200389	R# CE H120E F 0W12 1206	1
R496	P200083	R# CE H 2K7 J 0W12 1206	1	R567	P200389	R# CE H120E F 0W12 1206	1
R497	P200025	R# CE H 10E J 0W12 1206	1	R568	P200029	R# CE H 15E J 0W12 1206	1
R500	P200384	R# CE H 75E F 0W12 1206	1	R569	P200083	R# CE H 2K7 J 0W12 1206	1
R501	P200049	R# CE H100E J 0W12 1206	1	R570	P200384	R# CE H 75E F 0W12 1206	1
R502	P200111	R# CE H 39K J 0W12 1206	1	R571	P200049	R# CE H100E J 0W12 1206	1
R503	P200111	R# CE H 39K J 0W12 1206	1	R572	P200085	R# CE H 3K3 J 0W12 1206	1
R504	P200049	R# CE H100E J 0W12 1206	1	R573	P200085	R# CE H 3K3 J 0W12 1206	1
R505	P200057	R# CE H220E J 0W12 1206	1	R574	P200049	R# CE H100E J 0W12 1206	1
R506	P200083	R# CE H 2K7 J 0W12 1206	1	R575	P200083	R# CE H 2K7 J 0W12 1206	1
R507	P200107	R# CE H 27K J 0W12 1206	1	R576	P200025	R# CE H 10E J 0W12 1206	1
R508	P200397	R# CE H270E F 0W12 1206	1	R577	P200051	R# CE H120E J 0W12 1206	1
R509	P200397	R# CE H270E F 0W12 1206	1	R578	P200049	R# CE H100E J 0W12 1206	1
R510	P200390	R# CE H130E F 0W12 1206	1	R579	P200095	R# CE H 8K2 J 0W12 1206	1
R511	P200109	R# CE H 33K J 0W12 1206	1	R580	P200389	R# CE H120E F 0W12 1206	1
R512	P200109	R# CE H 33K J 0W12 1206	1	R581	P200389	R# CE H120E F 0W12 1206	1
R513	P200083	R# CE H 2K7 J 0W12 1206	1	R582	P200031	R# CE H 18E J 0W12 1206	1
R514	P200384	R# CE H 75E F 0W12 1206	1	R583	P200059	R# CE H270E J 0W12 1206	1
R515	P200049	R# CE H100E J 0W12 1206	1	R584	P200103	R# CE H 18K J 0W12 1206	1
R516	P200111	R# CE H 39K J 0W12 1206	1	R585	P200097	R# CE H 10K J 0W12 1206	1
R517	P200111	R# CE H 39K J 0W12 1206	1	R586	P200089	R# CE H 4K7 J 0W12 1206	1
R518	P200049	R# CE H100E J 0W12 1206	1	R587	P200071	R# CE H820E J 0W12 1206	1
R519	P200057	R# CE H220E J 0W12 1206	1	R588	P200059	R# CE H270E J 0W12 1206	1
R520	P200397	R# CE H270E F 0W12 1206	1	R589	P200407	R# CE H680E F 0W12 1206	1
R521	P200397	R# CE H270E F 0W12 1206	1	R590	P200053	R# CE H150E J 0W12 1206	1
R522	P200390	R# CE H130E F 0W12 1206	1	R591	P200059	R# CE H270E J 0W12 1206	1
R523	P200083	R# CE H 2K7 J 0W12 1206	1	R592	P200065	R# CE H470E J 0W12 1206	1
R524	P200049	R# CE H100E J 0W12 1206	1	R593	P200065	R# CE H470E J 0W12 1206	1
R525	P200111	R# CE H 39K J 0W12 1206	1	R594	P200129	R# CE H220K J 0W12 1206	1
R526	P200111	R# CE H 39K J 0W12 1206	1	R595	P200109	R# CE H 33K J 0W12 1206	1
R527	P200049	R# CE H100E J 0W12 1206	1	R596	P200017	R# CE H 4E7 J 0W12 1206	1
R528	P200055	R# CE H180E J 0W12 1206	1	R597	P200049	R# CE H100E J 0W12 1206	1
R529	P200083	R# CE H 2K7 J 0W12 1206	1	R598	P200049	R# CE H100E J 0W12 1206	1
R530	P200107	R# CE H 27K J 0W12 1206	1	R599	P200069	R# CE H680E J 0W12 1206	1
R531	P200399	R# CE H330E F 0W12 1206	1	R600	P200075	R# CE H 1K2 J 0W12 1206	1

R601	P200065	R# CE H470E J 0W12 1206	1	R654	P200057	R# CE H220E J 0W12 1206	1
R602	P200094	R# CE H 7K5 J 0W12 1206	1	R655	P200109	R# CE H 33K J 0W12 1206	1
R603	P200107	R# CE H 27K J 0W12 1206	1	R656	P200025	R# CE H 10E J 0W12 1206	1
R604	P200113	R# CE H 47K J 0W12 1206	1	R700	P200041	R# CE H 47E J 0W12 1206	1
R605	P200065	R# CE H470E J 0W12 1206	1	R701	P200041	R# CE H 47E J 0W12 1206	1
R606	P200059	R# CE H270E J 0W12 1206	1	R720	P200091	R# CE H 5K6 J 0W12 1206	1
R607	P200085	R# CE H 3K3 J 0W12 1206	1	R721	P200091	R# CE H 5K6 J 0W12 1206	1
R608	P200073	R# CE H 1K J 0W12 1206	1	R722	P200079	R# CE H 1K8 J 0W12 1206	1
R609	P200133	R# CE H330K J 0W12 1206	1	R723	P200105	R# CE H 22K J 0W12 1206	1
R610	P200115	R# CE H 56K J 0W12 1206	1	R740	P200073	R# CE H 1K J 0W12 1206	1
R611	P200079	R# CE H 1K8 J 0W12 1206	1	R767	P200057	R# CE H220E J 0W12 1206	1
R612	P200079	R# CE H 1K8 J 0W12 1206	1	R773	P200057	R# CE H220E J 0W12 1206	1
R613	P200079	R# CE H 1K8 J 0W12 1206	1	R776	P200057	R# CE H220E J 0W12 1206	1
R614	P200079	R# CE H 1K8 J 0W12 1206	1	R781	P200073	R# CE H 1K J 0W12 1206	1
R615	P200097	R# CE H 10K J 0W12 1206	1	R782	P200073	R# CE H 1K J 0W12 1206	1
R616	P200079	R# CE H 1K8 J 0W12 1206	1	R783	P200097	R# CE H 10K J 0W12 1206	1
R617	P200097	R# CE H 10K J 0W12 1206	1	R785	P200041	R# CE H 47E J 0W12 1206	1
R618	P200079	R# CE H 1K8 J 0W12 1206	1	R786	P200041	R# CE H 47E J 0W12 1206	1
R619	P200073	R# CE H 1K J 0W12 1206	1				
R620	P200097	R# CE H 10K J 0W12 1206	1	SR 2	R1011009	R CFFH 1E J 0W25	1
R621	P200097	R# CE H 10K J 0W12 1206	1	SR 3	R1011009	R CFFH 1E J 0W25	1
R622	P200097	R# CE H 10K J 0W12 1206	1	SR 4	R1011009	R CFFH 1E J 0W25	1
R623	P200097	R# CE H 10K J 0W12 1206	1	SR 5	R1011907	R CFFH E1 J 0W4	1
R624	P200113	R# CE H 47K J 0W12 1206	1				
R625	P200073	R# CE H 1K J 0W12 1206	1	T 1	R313729	J PIN TESTEYE	1
R626	P200051	R# CE H120E J 0W12 1206	1				
R627	P200075	R# CE H 1K2 J 0W12 1206	1	T200	R313729	J PIN TESTEYE	1
R628	P200097	R# CE H 10K J 0W12 1206	1	T201	R313729	J PIN TESTEYE	1
R629	P200077	R# CE H 1K5 J 0W12 1206	1	T300	R313729	J PIN TESTEYE	1
R630	P200073	R# CE H 1K J 0W12 1206	1	T301	R313729	J PIN TESTEYE	1
R631	P200073	R# CE H 1K J 0W12 1206	1	T400	R313729	J PIN TESTEYE	1
R632	P200081	R# CE H 2K2 J 0W12 1206	1	T401	R313729	J PIN TESTEYE	1
R633	P200081	R# CE H 2K2 J 0W12 1206	1	TGND	R313729	J PIN TESTEYE	1
R634	P200081	R# CE H 2K2 J 0W12 1206	1				
R635	P200081	R# CE H 2K2 J 0W12 1206	1	Z 1	P234164	D#ZEN 5V6 0W5 C DMMELF	1
R636	P200081	R# CE H 2K2 J 0W12 1206	1	Z 2	P234165	D#ZEN 4V7 0W5 C DMMELF	1
R637	P200041	R# CE H 47E J 0W12 1206	1	Z 3	P234165	D#ZEN 4V7 0W5 C DMMELF	1
R638	P200041	R# CE H 47E J 0W12 1206	1	Z 4	P234165	D#ZEN 4V7 0W5 C DMMELF	1
R639	P200049	R# CE H100E J 0W12 1206	1	Z150	P234057	D#ZEN 8V2 0W5 C DMMELF	1
R640	P200065	R# CE H470E J 0W12 1206	1	Z250	P234046	D#ZEN 12V 0W5 C DMMELF	1
R641	P200384	R# CE H 75E F 0W12 1206	1	Z350	P234046	D#ZEN 12V 0W5 C DMMELF	1
R642	P200073	R# CE H 1K J 0W12 1206	1	Z450	P234046	D#ZEN 12V 0W5 C DMMELF	1
R643	P200081	R# CE H 2K2 J 0W12 1206	1	Z500	P234268	D#BZV55C6V8 DMMELF	1
R650	P200097	R# CE H 10K J 0W12 1206	1	Z620	P234089	D#ZEN 13V 0W5 C DMMELF	1
R652	P200057	R# CE H220E J 0W12 1206	1	Z621	R131771	D ZEN 150V 3W25 C SOD57	1
R653	P200057	R# CE H220E J 0W12 1206	1	Z720	P234164	D#ZEN 5V6 0W5 C DMMELF	1






CONTRAST MODULATION KIT R9828140  
(module R762484)



To SYNCHRONISATION UNIT (J757)




COMP.	LOC.	COMP.	LOC.
C1	B 3	R1	B 2
C2	B 3	R2	B 3
C3	B 3	R3	B 3
C4	B 4	R4	B 4
C5	B 4	R5	B 4
C6	B 4	R6	B 4
C7	B 4	R7	B 4
C8	B 4	R8	B 4
C9	B 4	R9	B 4
C10	B 3	R10	B 4
C12	B 3	R11	B 4
C13	B 3	R12	B 4
C14	B 3	R13	B 4
C15	B 3	R14	B 3
C30	C 3	R15	B 3
C31	B 4	R16	B 3
C33	B 4	R17	B 3
C34	B 4	R18	B 3
C35	C 4	R19	B 3
C38	C 4	R20	B 3
C39	C 4	R21	C 3
C40	C 4	R22	B 3
C41	C 3	R23	B 3
C42	B 3	R24	B 3
C43	C 3	R25	B 3
C44	C 3	R26	B 3
C70	B 3	R30	B 2
C71	B 2	R31	B 4
C72	B 3	R32	B 4
C73	C 2	R33	B 4
C80	C 2	R34	B 4
C90	C 2	R35	C 4
C100	C 2	R36	C 4
C10	B 2	R37	C 4
C20	B 3	R39	B 4
C21	B 3	R40	B 4
C22	C 2	R41	C 4
C30	B 3	R42	B 4
C31	C 2	R43	C 4
C32	C 2	R44	C 3
C33	B 3	R45	C 3
C34	B 3	R46	B 4
C35	B 3	R47	B 3
C40	B 2	R48	C 3
C41	B 2	R49	B 3
C42	B 2	R50	C 3
C43	B 2	R51	C 3
C44	B 3	R52	C 3
C45	B 2	R53	C 3
C46	B 3	R54	C 3
C47	B 2	R55	C 3
C48	B 2	R70	B 2
C49	B 2	R71	B 2
C50	B 2	R72	C 2
		R73	C 2
D1	B 2	R80	C 2
D2	B 2	R81	B 2
D3	B 2	R82	B 2
D4	B 2	R83	B 2
D5	B 2	R84	C 2
D6	B 2	R85	B 2
D7	B 2	R86	B 2
D8	B 2	R87	C 2
D9	B 2	R88	C 2
D10	B 2	R89	C 2
		R90	C 2
FIDT	B 4	R91	B 2
FID2T	C 1	R92	B 2
FID3T	C 4	R93	B 2
		R94	B 2
IC1	B 3	R95	B 2
IC2	B 3	R96	B 2
IC3	B 3	R97	B 2
IC4	C 3	R98	C 2
IC5	C 3	R99	C 2
IC7	B 3	R100	C 2
IC8	C 3	R101	C 2
IC9	B 2	R102	C 2
IC10	C 2	R103	C 2
IC12	B 3	R104	C 2
IC13	B 2	R105	C 2
IC14	B 2	R106	C 2
IC15	B 2	R107	C 2
IC20	B 3	R108	C 2
		R109	C 2
J.757	B 1	R110	C 2
J4	B 2	R11	C 2
J6	B 2	R12	C 2
J10	B 1	R13	C 2
J11	B 1	R15	B 2
J12	C 1	R16	B 2
		R17	B 2
MP1	B 3	R18	B 2
MP2	C 3	R19	B 2
MP3	B 3	R20	B 3
MP4	B 3	R22	B 3
MP5	B 4	R23	B 3
MP6	B 3	R24	C 3
MP7	B 2	R25	B 3
MP8	B 2	R26	B 3
MP9	B 2	R27	C 2
		R28	C 2
P1	B 3	R40	B 2
P2	C 4	R41	B 2
		R42	B 2
Q1	B 4	R43	B 2
Q2	B 4	R51	B 2
Q3	B 4	R52	B 2
Q4	B 4		
		SRI	B 2


Name: CONTRAST MODULATION Article nr.: 76 2484-1  
 Date: 26-04-1995 Drawn: JVDY Checked: KBV

BARCO PROJECTION SYSTEMS

Modifications reserved








COMP. LOC. COMP. LOC.

C1	B	2	R11	D	1
C2	B	2	R12	B	1
C3	C	2	R13	D	1
C4	C	2	R14	B	1
C5	C	2	R15	D	1
C6	C	2	R16	B	1
C7	C	2	R17	D	1
C8	C	2	R18	B	1
C9	C	2	R19	D	1
C10	C	2	R20	B	1
C11	C	2	R21	D	1
C12	C	2	R22	B	1
C13	C	2	R23	D	1
C14	C	2	R24	B	1
C15	C	2	R25	D	1
C16	C	2	R26	B	1
C17	C	2	R27	D	1
C18	C	2	R28	B	1
C19	C	2	R29	D	1
C20	C	2	R30	B	1
C21	C	2	R31	D	1
C22	C	2	R32	B	1
C23	C	2	R33	D	1
C24	C	2	R34	B	1
C25	C	2	R35	D	1
C26	C	2	R36	B	1
C27	C	2	R37	D	1
C28	C	2	R38	B	1
C29	C	2	R39	D	1
C30	C	2	R40	B	1
C31	C	2	R41	D	1
C32	C	2	R42	B	1
C33	C	2	R43	D	1
C34	C	2	R44	B	1
C35	C	2	R45	D	1
C36	C	2	R46	B	1
C37	C	2	R47	D	1
C38	C	2	R48	B	1
C39	C	2	R49	D	1
C40	C	2	R50	B	1
C41	C	2	R51	D	1
C42	C	2	R52	B	1
C43	C	2	R53	D	1
C44	C	2	R54	B	1
C45	C	2	R55	D	1
C46	C	2	R56	B	1
C47	C	2	R57	D	1
C48	C	2	R58	B	1
C49	C	2	R59	D	1
C50	C	2	R60	B	1
D1	A	1	R90	J	3
D2	A	2	R91	J	3
D3	A	5	R92	J	3
D4	A	5	R93	J	3
D5	K	1	R94	J	3
D6	K	1	R95	J	3
D7	L	1	R96	J	3
D8	L	1	R97	J	3
D9	L	1	R98	J	3
D10	L	1	R99	J	3
IC1	D	2	R100	J	3
IC1	F	1	R101	J	3
IC1	F	2	R102	J	3
IC1	F	3	R103	J	3
IC1	L	4	R104	J	3
IC1	L	4	R105	J	3
IC2	H	6	R106	J	3
IC2	D	6	R107	J	3
IC2	C	1	R108	J	3
IC2	K	4	R109	J	3
IC2	C	4	R110	J	3
IC3	E	1	R111	J	3
IC4	F	5	R112	J	3
IC4	F	5	R113	J	3
IC4	K	4	R114	J	3
IC4	D	4	R115	J	3
IC5	E	4	R116	J	3
IC7	H	3	R117	J	3
IC9	J	1	R118	J	3
IC11	J	6	R119	J	3
IC11	J	3	R120	J	3
IC11	J	2	R121	J	3
IC11	J	4	R122	J	3
IC11	L	4	R123	J	3
IC12	K	5	R124	J	3
IC12	A	4	R125	J	3
IC12	A	4	R126	J	3
IC12	B	5	R127	J	3
IC12	B	5	R128	J	3
IC12	A	3	R129	J	3
IC12	A	4	R130	J	3
IC13	L	2	R131	J	3
IC14	L	2	R132	J	3
IC15	L	2	R133	J	3
IC20	B	1	R134	J	3
IC20	B	2	R135	J	3
IC20	K	5	R136	J	3
J4	A	6	R137	J	3
J8	A	6	R138	J	3
J757A	A	5	R139	J	3
J10	J	1	R140	J	3
J11	J	1	R141	J	3
J12	J	1	R142	J	3
MP1	D	2	R143	J	3
MP2	D	5	R144	J	3
MP3	G	1	R145	J	3
MP4	G	4	R146	J	3
MP5	B	5	R147	J	3
MP6	B	5	R148	J	3
MP7	L	1	R149	J	3
MP8	L	1	R150	J	3
MP9	L	1	R151	J	3
P1	D	1	R152	J	3
P2	D	4	R153	J	3
Q1	C	2	R154	J	3
Q2	C	2	R155	J	3
Q3	C	5	R156	J	3
Q4	C	4	R157	J	3
R1	A	2	R158	J	3
R2	A	2	R159	J	3
R3	A	2	R160	J	3
R4	C	2	R161	J	3
R5	C	2	R162	J	3
R6	C	2	R163	J	3
R7	C	2	R164	J	3
R8	C	1	R165	J	3
R9	C	1	R166	J	3
R10	D	2	R167	J	3

BARCO




# PRODUCT SAFETY NOTICE

COMPONENTS MARKED WITH \* OR Δ HAVE SPECIAL CHARACTERISTICS IMPORTANT TO SAFETY. BEFORE REPLACING ANY OF THESE COMPONENTS, READ CAREFULLY THE SERVICE SAFETY PRECAUTIONS. DO NOT DEGRADE THE SAFETY OF THIS SET THROUGH IMPROPER SERVICING.

Name	CONTRAST MODULATION	Article nr.	76 2484-1
Date	03-05-1995	Drawn	JVDY
		Checked	KBU
BARCO PROJECTION SYSTEMS			




## Electrical connection



Connect the CONTRAST MOD. module to the RGB Input+Driver module by plugging in the CONTRAST\_MOD plug into the CONTRAST\_MOD connector (J757) on the input module

## Mechanical mounting

Place the CONTRAST MOD. module on the mechanical frame lining up the two holes in the module with the threaded holes in the frame. Fix the module to the frame by inserting and tightening the two provided screws.




Parts listing CONTAST MOD. module R762484

SIT.	ITEM NO.	DESCRIPTION	QUANTITY	SIT.	ITEM NO.	DESCRIPTION	QUANTITY
9000	R3631049	SCR D933 M 3 X 6 XIC	2	D 8	P234099	D#4148 R DMMELF	1
C 1	P210013	C# COG MU 1N J 50 1206	1	D 9	P234099	D#4148 R DMMELF	1
C 2	P210055	C# COG MU 390P F 50 0805	1	D 10	P234099	D#4148 R DMMELF	1
C 3	P210140	C# X7R MU 4N7K 50 1206	1	I 1	P230705	U#34084 MC SOL16 P	1
C 4	P210169	C# X7R MU 220N K 50 1210	1	I 2	P230328	U#064 TL SO14 I	1
C 5	P212018	C# TA 10M M 16 6032	1	I 3	R134225	U 2082 EL DIP8 P	1
C 6	P210136	C# Y5V MU 330N Z 50 1206	1	I 4	P230328	U#064 TL SO14 I	1
C 7	P212018	C# TA 10M M 16 6032	1	I 5	R134225	U 2082 EL DIP8 P	1
C 8	P210213	C# Y5V MU 100N Z 25 0805	1	I 7	P230653	U#76013 SC SOL28 P	1
C 9	P210213	C# Y5V MU 100N Z 25 0805	1	I 8	P230653	U#76013 SC SOL28 P	1
C 11	P210213	C# Y5V MU 100N Z 25 0805	1	I 9	P230653	U#76013 SC SOL28 P	1
C 12	P210213	C# Y5V MU 100N Z 25 0805	1	I 11	P230705	U#34084 MC SOL16 P	1
C 13	P210213	C# Y5V MU 100N Z 25 0805	1	I 12	P230103	U#74HCT04 SO14 I	1
C 14	P210132	C# COG MU 3P3D 50 0805	1	I 13	P230374	U#317 LM SO8 P	1
C 15	P210213	C# Y5V MU 100N Z 25 0805	1	I 14	P230905	U#337L LM SO8 P	1
C 30	P210178	C# Y5V MU 1M Z 16 1206	1	I 15	P230062	U#78L05A LM SO8 P	1
C 31	P210178	C# Y5V MU 1M Z 16 1206	1	I 20	P230073	U#74HCT123 SO16 I	1
C 33	P210213	C# Y5V MU 100N Z 25 0805	1	J757	R3484128	CD CT FTMS P12 70	1
C 34	P210169	C# X7R MU 220N K 50 1210	1	MP 1	R313729	J PIN TESTEYE	1
C 35	P212018	C# TA 10M M 16 6032	1	MP 2	R313729	J PIN TESTEYE	1
C 38	P212018	C# TA 10M M 16 6032	1	MP 3	R313729	J PIN TESTEYE	1
C 39	P210213	C# Y5V MU 100N Z 25 0805	1	MP 4	R313729	J PIN TESTEYE	1
C 40	P210213	C# Y5V MU 100N Z 25 0805	1	MP 5	R313729	J PIN TESTEYE	1
C 41	P210213	C# Y5V MU 100N Z 25 0805	1	MP 6	R313729	J PIN TESTEYE	1
C 42	P210213	C# Y5V MU 100N Z 25 0805	1	MP 7	R313729	J PIN TESTEYE	1
C 43	P210132	C# COG MU 3P3D 50 0805	1	MP 8	R313729	J PIN TESTEYE	1
C 44	P210213	C# Y5V MU 100N Z 25 0805	1	MP 9	R313729	J PIN TESTEYE	1
C 70	P210213	C# Y5V MU 100N Z 25 0805	1	P 1	P201375	R#TCE H 2K M 0W1 S4 TO	1
C 71	P210213	C# Y5V MU 100N Z 25 0805	1	P 2	P201375	R#TCE H 2K M 0W1 S4 TO	1
C 72	P210213	C# Y5V MU 100N Z 25 0805	1	PC	R780374	PCD#PJ53 D700 C_M	1
C 73	P210213	C# Y5V MU 100N Z 25 0805	1	Q 1	P232118	Q#BSS87 F SS SOT89	1
C 80	P210019	C# COG MU 47P J 50 0805	1	Q 2	P232044	Q#BC859B P SS SOT23	1
C 90	P210019	C# COG MU 47P J 50 0805	1	Q 3	P232043	Q#BC849B N SS SOT23	1
C100	P210019	C# COG MU 47P J 50 0805	1	Q 4	P232044	Q#BC859B P SS SOT23	1
C110	P210213	C# Y5V MU 100N Z 25 0805	1	R 1	P200725	R# CE H100E J 0W1 0805	1
C120	P210213	C# Y5V MU 100N Z 25 0805	1	R 2	P201107	R# CE H 6K8 F 0W1 0805	1
C121	P210213	C# Y5V MU 100N Z 25 0805	1	R 3	P201094	R# CE H 2K F 0W1 0805	1
C122	P210213	C# Y5V MU 100N Z 25 0805	1	R 4	P201093	R# CE H 1K8 F 0W1 0805	1
C130	P210213	C# Y5V MU 100N Z 25 0805	1	R 5	P201156	R# CE H750K F 0W1 0805	1
C131	P210213	C# Y5V MU 100N Z 25 0805	1	R 6	P201107	R# CE H 6K8 F 0W1 0805	1
C132	P210213	C# Y5V MU 100N Z 25 0805	1	R 7	P201109	R# CE H 8K2 F 0W1 0805	1
C133	P210213	C# Y5V MU 100N Z 25 0805	1	R 8	P200749	R# CE H 1K J 0W1 0805	1
C134	P210213	C# Y5V MU 100N Z 25 0805	1	R 9	P200733	R# CE H220E J 0W1 0805	1
C135	P210213	C# Y5V MU 100N Z 25 0805	1	R 10	P201139	R# CE H150K F 0W1 0805	1
C140	P212018	C# TA 10M M 16 6032	1	R 11	P201125	R# CE H 39K F 0W1 0805	1
C141	P210213	C# Y5V MU 100N Z 25 0805	1	R 12	P200701	R# CE H 10E J 0W1 0805	1
C142	P212018	C# TA 10M M 16 6032	1	R 13	P201093	R# CE H 1K8 F 0W1 0805	1
C143	P210213	C# Y5V MU 100N Z 25 0805	1	R 14	P200701	R# CE H 10E J 0W1 0805	1
C144	P210213	C# Y5V MU 100N Z 25 0805	1	R 15	P200725	R# CE H100E J 0W1 0805	1
C145	P212018	C# TA 10M M 16 6032	1	R 16	P201087	R# CE H 1K F 0W1 0805	1
C146	P210213	C# Y5V MU 100N Z 25 0805	1	R 17	P200701	R# CE H 10E J 0W1 0805	1
C147	P212018	C# TA 10M M 16 6032	1	R 18	P201087	R# CE H 1K F 0W1 0805	1
C148	P210136	C# Y5V MU 330N Z 50 1206	1	R 19	P201111	R# CE H 10K F 0W1 0805	1
C149	P210213	C# Y5V MU 100N Z 25 0805	1	R 20	P201117	R# CE H 18K F 0W1 0805	1
C150	P212018	C# TA 10M M 16 6032	1	R 21	P200725	R# CE H100E J 0W1 0805	1
D 1	P234099	D#4148 R DMMELF	1	R 22	P201111	R# CE H 10K F 0W1 0805	1
D 2	P234099	D#4148 R DMMELF	1	R 23	P201111	R# CE H 10K F 0W1 0805	1
D 3	P234099	D#4148 R DMMELF	1				
D 4	P234099	D#4148 R DMMELF	1				
D 5	P234099	D#4148 R DMMELF	1				
D 6	P234099	D#4148 R DMMELF	1				
D 7	P234099	D#4148 R DMMELF	1				

R 24	P201079	R# CE H470E F 0W1 0805	1	R116	P201055	R# CE H 47E F 0W1 0805	1
R 25	P201087	R# CE H 1K F 0W1 0805	1	R117	P200725	R# CE H100E J 0W1 0805	1
R 26	P201079	R# CE H470E F 0W1 0805	1	R118	P200725	R# CE H100E J 0W1 0805	1
R 30	P200725	R# CE H100E J 0W1 0805	1	R119	P200725	R# CE H100E J 0W1 0805	1
R 31	P200757	R# CE H 2K2 J 0W1 0805	1	R120	P201108	R# CE H 7K5 F 0W1 0805	1
R 32	P201156	R# CE H750K F 0W1 0805	1	R122	P201091	R# CE H 1K5 F 0W1 0805	1
R 33	P200757	R# CE H 2K2 J 0W1 0805	1	R123	P201081	R# CE H560E F 0W1 0805	1
R 34	P201139	R# CE H150K F 0W1 0805	1	R124	P201081	R# CE H560E F 0W1 0805	1
R 35	P201097	R# CE H 2K7 F 0W1 0805	1	R125	P201135	R# CE H100K F 0W1 0805	1
R 36	P201125	R# CE H 39K F 0W1 0805	1	R126	P201111	R# CE H 10K F 0W1 0805	1
R 37	P200701	R# CE H 10E J 0W1 0805	1	R127	P201139	R# CE H150K F 0W1 0805	1
R 39	P200733	R# CE H220E J 0W1 0805	1	R128	P201119	R# CE H 22K F 0W1 0805	1
R 40	P200765	R# CE H 4K7 J 0W1 0805	1	R140	P200733	R# CE H220E J 0W1 0805	1
R 41	P201107	R# CE H 6K8 F 0W1 0805	1	R141	P201075	R# CE H330E F 0W1 0805	1
R 42	P201109	R# CE H 8K2 F 0W1 0805	1	R142	P200715	R# CE H 39E J 0W1 0805	1
R 43	P201087	R# CE H 1K F 0W1 0805	1	R143	P201065	R# CE H120E F 0W1 0805	1
R 44	P200725	R# CE H100E J 0W1 0805	1	R151	P200701	R# CE H 10E J 0W1 0805	1
R 45	P200701	R# CE H 10E J 0W1 0805	1	R152	P200701	R# CE H 10E J 0W1 0805	1
R 46	P200701	R# CE H 10E J 0W1 0805	1				
R 47	P201087	R# CE H 1K F 0W1 0805	1	SR 1	R1011129	R CFFH 10E J 0W25	1
R 48	P201111	R# CE H 10K F 0W1 0805	1				
R 49	P201111	R# CE H 10K F 0W1 0805	1				
R 50	P201111	R# CE H 10K F 0W1 0805	1				
R 51	P200725	R# CE H100E J 0W1 0805	1				
R 52	P201111	R# CE H 10K F 0W1 0805	1				
R 53	P201087	R# CE H 1K F 0W1 0805	1				
R 54	P201085	R# CE H820E F 0W1 0805	1				
R 55	P201087	R# CE H 1K F 0W1 0805	1				
R 70	P200717	R# CE H 47E J 0W1 0805	1				
R 71	P200717	R# CE H 47E J 0W1 0805	1				
R 72	P200717	R# CE H 47E J 0W1 0805	1				
R 73	P200717	R# CE H 47E J 0W1 0805	1				
R 80	P201111	R# CE H 10K F 0W1 0805	1				
R 81	P201111	R# CE H 10K F 0W1 0805	1				
R 82	P201111	R# CE H 10K F 0W1 0805	1				
R 83	P201111	R# CE H 10K F 0W1 0805	1				
R 84	P201111	R# CE H 10K F 0W1 0805	1				
R 85	P201111	R# CE H 10K F 0W1 0805	1				
R 86	P201111	R# CE H 10K F 0W1 0805	1				
R 87	P201113	R# CE H 12K F 0W1 0805	1				
R 88	P201122	R# CE H 30K F 0W1 0805	1				
R 89	P201087	R# CE H 1K F 0W1 0805	1				
R 90	P201094	R# CE H 2K F 0W1 0805	1				
R 91	P201111	R# CE H 10K F 0W1 0805	1				
R 92	P201111	R# CE H 10K F 0W1 0805	1				
R 93	P201111	R# CE H 10K F 0W1 0805	1				
R 94	P201111	R# CE H 10K F 0W1 0805	1				
R 95	P201111	R# CE H 10K F 0W1 0805	1				
R 96	P201111	R# CE H 10K F 0W1 0805	1				
R 97	P201111	R# CE H 10K F 0W1 0805	1				
R 98	P201113	R# CE H 12K F 0W1 0805	1				
R 99	P201122	R# CE H 30K F 0W1 0805	1				
R100	P201087	R# CE H 1K F 0W1 0805	1				
R101	P201093	R# CE H 1K8 F 0W1 0805	1				
R102	P201103	R# CE H 4K7 F 0W1 0805	1				
R103	P201111	R# CE H 10K F 0W1 0805	1				
R104	P201111	R# CE H 10K F 0W1 0805	1				
R105	P201111	R# CE H 10K F 0W1 0805	1				
R106	P201111	R# CE H 10K F 0W1 0805	1				
R107	P201111	R# CE H 10K F 0W1 0805	1				
R108	P201111	R# CE H 10K F 0W1 0805	1				
R109	P201111	R# CE H 10K F 0W1 0805	1				
R110	P201113	R# CE H 12K F 0W1 0805	1				
R111	P201122	R# CE H 30K F 0W1 0805	1				
R112	P201075	R# CE H330E F 0W1 0805	1				
R113	P201087	R# CE H 1K F 0W1 0805	1				
R115	P201055	R# CE H 47E F 0W1 0805	1				




IBCL LINKING KIT R9827861  
(module R762485)




Electrical connection

- Connect the IBCL\_LINKING module to the RGB Input+Driver module by plugging in the BCL\_LINK\_INT plug (A) into the BCL\_LINK\_INT connector (J778) on the input module
- !! Cut the two wires (1&2) on the input module to allow BCL Linking operation (see illustration below)



Mechanical mounting

Place the IBCL LINKING module on the mechanical frame lining up the two holes in the module with the threaded holes in the frame. Fix the module to the frame by inserting and tightening the two provided screws (B).





RS 232 AND  
IR RECIEVER  
MODULE


RGB INPUT  
AND DRIVER  
MODULE

WIRE-UNIT

LINKED  
BCL  
MODULE


RS 232 IN  
J710

RS 232 OUT  
J711



J779  
M/S.SELECT.700  
MASTER.CONTR

J713  
M/S.SELECT.700  
MASTER.CONTR






M/S.SELECT  
MASTER : LOW  
SLAVE : HIGH

# LINKED BCL

Name LINKED BCL		Article nr. 701 series	
Date 22-03-1995	Drawn JVDY	Checked KBU	

BARCO PROJECTION SYSTEMS



ONLY FOR 800 SERIES  
TO IBCL-LINK UNIT

700 SERIES : FROM INPUT DRIVER (J778)  
800 SERIES : FROM DECODER (J4)

COMP.	LOC.	COMP.	LOC.
C1	B 2	J1	C 3
C2	C 2	J2	C 3
C3	B 2		
C4	C 2	R1	B 2
C5	C 1	R2	B 2
C6	C 2	R3	B 2
C7	C 2	R4	C 2
C9	C 2	R5	C 2
		R6	C 2
D1	B 2	R7	C 2
D2	C 2	R8	C 2
		R9	B 2
F101	B 3	R10	C 2
F102	C 3	R11	C 2
F103	C 3	R12	C 1
		R13	C 2
IC1	C 2	R14	C 2
IC2	C 2	R15	C 2
		R16	C 2
		REL1	C 3

Name	LINKED BCL UNIT	Article nr.	76 2485-1
Date	26-04-1995	Drawn	JVDY
		Checked	KBU

BARCO PROJECTION SYSTEMS

Modifications reserved





Parts listing IBCL\_LINKING module R762485

SIT.	ITEM NO.	DESCRIPTION	QUANTITY	SIT.	ITEM NO.	DESCRIPTION	QUANTITY
3000	R3484092	CD CT FTMT P 9 100	1	J 1	R313923	J CT H MBT P 3 M2SN	1
3100	R3485070	CD CT \$FTFT P7/3 400	1	PC	R780375	PCD#PJ53 D700 IBCL	1
110	R3631059	SCR D933 M 3 X 8 XIC	4	R 1	P200097	R# CE H 10K J 0W12 1206	1
100	R802666	SPR L17 D 6 M 3 B	2	R 2	P200080	R# CE H 2K J 0W12 1206	1
C 1	P210122	C# X7R MU 100N K 50 1206	1	R 3	P200674	R# CE H 8M2 K 0W12 1206	1
C 2	P210097	C# X7R MU 33N K 50 1206	1	R 4	P200065	R# CE H470E J 0W12 1206	1
C 3	P212031	C# TA 22M M 16 7343	1	R 5	P200137	R# CE H470K J 0W12 1206	1
C 4	P210122	C# X7R MU 100N K 50 1206	1	R 6	P200121	R# CE H100K J 0W12 1206	1
C 5	P210122	C# X7R MU 100N K 50 1206	1	R 7	P200121	R# CE H100K J 0W12 1206	1
C 6	P210122	C# X7R MU 100N K 50 1206	1	R 8	P200097	R# CE H 10K J 0W12 1206	1
C 7	P210122	C# X7R MU 100N K 50 1206	1	R 9	P200097	R# CE H 10K J 0W12 1206	1
C 9	P210122	C# X7R MU 100N K 50 1206	1	R 10	P200097	R# CE H 10K J 0W12 1206	1
D 1	P234099	D#4148 R DMMELF	1	R 11	P200137	R# CE H470K J 0W12 1206	1
D 2	P234099	D#4148 R DMMELF	1	R 12	P200080	R# CE H 2K J 0W12 1206	1
I 1	P230030	U#4053 SO16 I	1	R 13	P200097	R# CE H 10K J 0W12 1206	1
I 2	P230203	U#084 TL SO14 P	1	R 14	P200097	R# CE H 10K J 0W12 1206	1
				R 15	P200097	R# CE H 10K J 0W12 1206	1
				R 16	P200105	R# CE H 22K J 0W12 1206	1
				REL1	R324350	RLY 12V 2C BH DIP M	1